



972B DualMag™  
Vacuum Pressure Transducer  
**Models with RS-232/RS-485,  
EtherCAT®, or Digital Display**  
**Operation and Installation Manual**

P/N: 100017133  
972B DualMag™ Transducer  
Operation and Installation Manual  
Revision: K, February 2020

---

## Notice

**This product is intended for use by industrial customers and should be serviced only by MKS trained representatives. The service manuals and related materials are provided in English at no charge and are intended for use by experienced technicians. It is the responsibility of the user to obtain and assure the accuracy of any needed translations of manuals. If you require assistance, contact the MKS Customer Service group. The MKS Technical Support Group notifies users of record if safety-related upgrades or new hazards associated with the product are identified.**

### Damage Requiring Service

Disconnect the product from all power sources and refer servicing to Qualified Service Personnel under the following conditions:

- a. When any cable or plug is damaged.
- b. If any liquid has been spilled onto, or objects have fallen into the product.
- c. If the product has been exposed to rain or water.
- d. If the product does not operate normally even if you follow the operating instructions. Adjust only those controls that are covered by the operation instructions. Improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
- e. If the product has been dropped or the enclosure has been damaged.
- f. When the product exhibits a distinct change in performance. This indicates a need for service.

### Service and Warranty

Some minor problems are readily corrected on site. If the product requires service, contact the MKS Technical Support Department at +1-833-986-1686. If the product must be returned to the factory for service, request a Return Material Authorization (RMA) from MKS. Do not return products without first obtaining an RMA. In some cases, a hazardous materials disclosure form may be required. The MKS Customer Service Representative will advise you if the hazardous materials document is required.

When returning products to MKS, be sure to package the products to prevent shipping damage. Shipping damage on returned products due to inadequate packaging is the Buyer's responsibility.

#### Customer Service / Technical Support:

MKS Global Headquarters  
2 Tech Drive, Suite 201  
Andover MA, 01810 USA  
Phone: +1-833-986-1686  
Email: [insidesales@mksinst.com](mailto:insidesales@mksinst.com)  
Visit our website at: [www.mksinst.com](http://www.mksinst.com)

### Warranty Information

MKS Instruments, Inc. provides an eighteen (18) month warranty from the date of shipment for new MKS products. The MKS Instruments, Inc. general terms and conditions of sale provide the complete and exclusive warranty for MKS products. This document is located on our web site at [www.mksinst.com](http://www.mksinst.com), or may be obtained by a contacting an MKS customer service representative.

---

## Proprietary Information

This document contains confidential proprietary information belonging to MKS Instruments, Inc. This information is not for publication and has been provided to MKS on the condition that it not be copied, reproduced or disclosed, either wholly or in part, to third parties without the expressed written consent of MKS Instruments, Inc.

The information contained in this document is subject to change without notice.

## Copyright Information

© 2020 MKS Instruments, Inc. All rights reserved. Granville-Phillips® is a registered trademark of MKS Instruments, Inc., and mksinst™, DualTrans™, MicroPirani™, UniMag™, DualMag™, TriMag™, and QuadMag™ are trademarks of MKS Instruments Inc. Windows® is a trademark of Microsoft Corporation. All other trademarks and registered trademarks are the properties of their respective owners.

No part of this work may be reproduced by any method including photocopying and recording or by any information or retrieval system without written permission of MKS Instruments, Inc.

## Table of Contents

|                                                                           |    |
|---------------------------------------------------------------------------|----|
| Safety information .....                                                  | 4  |
| Symbols used: .....                                                       | 4  |
| Unpacking .....                                                           | 5  |
| Description .....                                                         | 6  |
| 972B Functions .....                                                      | 7  |
| User Switch (RS-232/RS-485 models only).....                              | 7  |
| LED Status Indicator .....                                                | 7  |
| EtherCAT Status Indicator .....                                           | 7  |
| Transducer installation (mechanical) .....                                | 8  |
| Transducer installation (electrical) .....                                | 9  |
| Serial user interface .....                                               | 12 |
| Communication Protocol.....                                               | 13 |
| Setpoint relays .....                                                     | 15 |
| Integrated Touch Display ( <i>not available in EtherCAT units</i> ).....  | 17 |
| Pressure output.....                                                      | 19 |
| Factory defaults .....                                                    | 26 |
| Transducer lock function ( <i>not available on EtherCAT units</i> ) ..... | 27 |
| User Switch Command ( <i>not available on EtherCAT units</i> ).....       | 27 |
| Transducer test ( <i>not available on EtherCAT units</i> ).....           | 27 |
| Analog output.....                                                        | 29 |
| MicroPirani gas dependence .....                                          | 49 |
| Query Command list .....                                                  | 52 |
| Setup and configuration command list.....                                 | 53 |
| Firmware upgrades (RS-232 only).....                                      | 54 |
| FAQ (Frequently Asked Questions).....                                     | 55 |
| Trouble shooting .....                                                    | 57 |
| Service and Repair .....                                                  | 58 |
| Specifications .....                                                      | 62 |
| 972B Transducer Dimensions.....                                           | 63 |
| Accessories and replacement part numbers .....                            | 64 |
| Index .....                                                               | 66 |

---

## Safety information:

### Symbols used:

The first symbol below is used throughout this manual to further define the safety concerns associated with the product. The last two symbols identify other information in this manual that is essential or useful in achieving optimal performance from the 972B DualMag transducer.

---

**Caution:**  Failure to read and follow the message could result in personal injury or serious damage to the equipment or both.

---

**Critical:**  Failure to read and follow the message could result in damage to the equipment.

---

**Attention:**  Calls attention to important procedures, practices or conditions.

---

## General safety information

The safety instructions should always be followed during installation and operation of the 972B DualMag transducer. [Pass safety information to all users.](#)

### Safety Precautions:



**Electrical connections.** The 972B must be properly electrically connected to perform according to the specifications. Output pins are not protected against wrong electrical connections. Wrong electrical connections can cause permanent damage to the transducer or interference to measuring performance. Refer to Electrical connections description, beginning on page 9.



**Fuse.** The 972B power supply input has an internal thermal fuse. The fuse is self-recoverable and should not be changed.



**Explosive Environments.** Do not use the 972B in presence of flammable gases or other explosive environments.

**Corrosive Environments.** The 972B is not intended for use in corrosive environments. Refer to Transducer installation, beginning on page 8.



**Service and Repair.** Do not substitute parts or modify instrument other than described in Service and Repair page 59. Do not install substituted parts or perform any unauthorized modification to the instrument. Return the instrument to a MKS Calibration and Service Center for service and repair to ensure all of the safety features are maintained.



**Magnetic interference.** The 972B contains a strong permanent magnet that can interfere with performance and operation of other electronics equipment and life support devices like pacemakers. Only install the 972B where it cannot interfere with other electronics.



**CE marking** The 972B transducer complies with European standards for CE marking.

---

## Unpacking

Before unpacking the 972B DualMag transducer, check all surfaces of the packing material for shipping damage. Inspect for visible damage. If found, notify the carrier immediately. Check to be sure the 972B package contains these items:

| Part number | Description       |
|-------------|-------------------|
| 972B-xxxxx  | 972B Transducer   |
| 100017132   | Quick Start Guide |

If any items are missing, call MKS Customer Service at +1-833-986-1686 or your local MKS sales office or distributor.

## Part number

The 971B, 972B, & 974B part number system has 5 digits that identify flange, communication interface, analog output type, I/O connector and sensor sealing type. Transducers can be delivered with customer configuration of various parameters such as setpoint settings and these specials have additional 4 digits after the regular part number.

|                                                                                                                                                             |                                 |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|
| <b>Transducer Model</b> .....                                                                                                                               | <b>Code</b>                     |
| 971B UniMag .....                                                                                                                                           | 971B-                           |
| 972B DualMag .....                                                                                                                                          | 972B-                           |
| 974B QuadMag .....                                                                                                                                          | 974B-                           |
| <b>Flange</b>                                                                                                                                               |                                 |
| NW25 KF .....                                                                                                                                               | 2                               |
| 2 3/4" CF .....                                                                                                                                             | 7                               |
| NW40 KF .....                                                                                                                                               | 9                               |
| <b>Interface</b>                                                                                                                                            |                                 |
| RS232 .....                                                                                                                                                 | 1                               |
| RS485 .....                                                                                                                                                 | 2                               |
| EtherCAT/Analog .....                                                                                                                                       | 7 (972B only)                   |
| <b>Analog Out</b>                                                                                                                                           |                                 |
| Standard MKS .....                                                                                                                                          | 0                               |
| <b>Connector Relays</b>                                                                                                                                     |                                 |
| SubD 15pin HD male/no relay .....                                                                                                                           | 2                               |
| SubD 15pin HD male/3 relays .....                                                                                                                           | 3 (not available with EtherCAT) |
| SubD 15pin HD male/3 relays/Dual Aout (piezo differential) - 974B only .....                                                                                | 4 (not available with EtherCAT) |
| SubD 15pin HD male/3 relays/Dual Aout (Absolute) - 972B/974B only .....                                                                                     | 5 (not available with EtherCAT) |
| <b>Enclosure Sealing</b>                                                                                                                                    |                                 |
| Standard/Viton® sealing .....                                                                                                                               | 0                               |
| IP54/Viton .....                                                                                                                                            | 2                               |
| Standard/Viton sealing/display .....                                                                                                                        | 4 (not available with EtherCAT) |
| <b>Accessories</b>                                                                                                                                          |                                 |
| PDR900 Single Channel Controller, RS232/485, US Power Cord .....                                                                                            | PDR900-12-US                    |
| Cable, PDR900 to 970B, 10 ft (3M), RS232 .....                                                                                                              | 100013620                       |
| Cable, PDR900 to 970B, 10 ft (3M), RS485 .....                                                                                                              | 100013671                       |
| Replacement Cold Cathode Anode Module .....                                                                                                                 | 970BNT-KIT                      |
| NW25KF Centering Ring with 4µm Filter and Viton O-ring* .....                                                                                               | 100014515                       |
| NW40KF Centering Ring with 4µm Filter and Viton O-ring* .....                                                                                               | 100014520                       |
| * Recommended on inlet flange of 972B/974B to protect sensors from particulates when used in harsh environments. Other filter sizes available upon request. |                                 |

(Ordering Code Example: 971B-21030 = KF25, RS232, standard analog output, Sub D 15 pin HD male, 3 relays, Viton.)

## Special versions

|             |                                                          |
|-------------|----------------------------------------------------------|
| Part number |                                                          |
| 972B-x1380  | Edwards WRG pin and output compatible                    |
| 972B-x1580  | Oerlikon PTR90, Inficon MPG400 pin and output compatible |
| 972B-x1590  | Pfeiffer PKR251 pin and output compatible                |
| 972B-x7020  | EtherCAT option, flange only                             |

## Description

The 972B DualMag™ vacuum transducer offers a wide measuring range from  $1 \times 10^{-8}$  Torr to atmosphere and is based on measurement of thermal conductivity and measurement cold cathode ionization current.



The 972B is designed for general purpose pressure measurement and control as a standalone unit or with the PDR900 display and controller unit.

The transducer uses RS-232 or RS-485 digital communication interface for setup of transducer parameters and to provide real time pressure measurement.

**NOTE: The EtherCAT model is not compatible with the PDR900.**


The 972B has up to three mechanical relays (*not available in EtherCAT units*) which can be used for process control, for example interlocking valves or pumps. The analog voltage output can be interfaced to external analog equipment for pressure readout or control.



### Sensor technology

The 972B transducer contains two separate sensor elements. The MicroPirani™ sensor element is based on measurement of thermal conductivity. The MicroPirani sensor consists of a silicon chip with a heated resistive element forming one surface of a cavity. A cover on top of the chip forms the other surface of the cavity. Due to the geometry of the sensor, convection cannot take place within the cavity and consequently the sensor is insensitive to mounting position. Gas molecules are passed by diffusion only to the heated element where the heat loss of the gas is measured.

The cold cathode inverted magnetron utilizes a high voltage anode, cathode and a permanent magnet. Electrons are accelerated towards the anode and will ionize molecules by collision. The magnetic field deflects the electrons, causing them to spiral as they move across the magnetic field to the anode. This spiraling movement increases the opportunity for them to encounter and ionize the molecules. The ionization of the molecules creates an electric current as a function of the pressure.



Both sensor elements are very robust and can withstand high G-forces and fast inrushes of air.

### Applications

The 972B can be used in many different vacuum applications within the semiconductor, analytical and coating industries:

- General vacuum pressure measurement
- Gas backfilling measurement and controlling
- Coating
- Mass spectrometer control
- System process control
- Sense abnormal pressure and take appropriate security measures using setpoint relays
- Control system pressure


### Disposal (European Union only)

The 972B transducer is manufactured according to the RoHS directive.



For the benefit of the environment, at the end of life of the 972B, it should not be disposed in the normal unsorted waste stream. It should be deposited at an appropriate collection point or facility to enable recovery or recycling.

## 972B Functions



### User Switch (RS-232/RS-485 models only)

The user switch has the following functions:

1. Vacuum Zero adjustment (VAC! Command)
2. MicroPirani Atmospheric adjustment (ATM! Command)
3. Transducer firmware upgrade mode



If the user switch is activated by accident and Vacuum Zero or Atmospheric adjustment is executed the original factory adjustment can be recovered using the FD!VAC or FD!ATM command. (See the factory defaults on page 26).

If the transducer is delivered with customer specified parameters, the User Switch is disabled. See page 27 to enable the switch.

### LED Status Indicator

The red/green LED status indicator has the following stages:

| LED Color   | Flash Interval | Status                                           |
|-------------|----------------|--------------------------------------------------|
| GREEN       | Solid          | Normal operation                                 |
| RED         | 2 sec          | Power on sequence                                |
| GREEN       | 1 sec          | Test mode TST!ON (see page 27)                   |
| GREEN flash | 3 flashes      | User Adjustment executed successfully            |
| RED flash   | 3 flashes      | User Adjustment failed                           |
| RED         | 2 sec          | User switch disabled                             |
| RED         | Solid          | Transducer defect                                |
| OFF         |                | Firmware upgrade mode (see page 53) or Power OFF |

### EtherCAT Status Indicator

| GREEN LED    | Flash Interval           | EtherCAT State   | RED LED      | Flash Interval           | EtherCAT State               |
|--------------|--------------------------|------------------|--------------|--------------------------|------------------------------|
| OFF          |                          | Initialization   | OFF          |                          | No Error                     |
| Blinking     | 200 ms                   | Pre Operational  | Blinking     | 200 ms                   | Invalid Configuration        |
| Single Flash | 100 ms ON<br>1000 ms OFF | Safe Operational | Flickering   | 50 ms ON<br>50 ms OFF    | Invalid Firmware             |
| Flickering   | 50 ms ON<br>50 ms OFF    | Bootstrap        | Single Flash | 100 ms ON<br>1000 ms OFF | Unsolicited State Change     |
| ON           |                          | Operational      | Double Flash |                          | Application Watchdog Timeout |
|              |                          |                  | ON           |                          | PDI Watchdog Timeout         |

---

## Transducer installation (mechanical)

---



**Do not use or install the 972B transducer where the following conditions occur:**

- Temperatures lower than 0 °C or higher than 40 °C
  - Corrosive or explosive gases
  - Direct sunlight or other heat sources
  - Magnetic fields
- 

### Process compatibility

The 972B transducer is intended for use in relatively clean environments. The transducer cannot be used in corrosive environments like a semiconductor etch process chamber where aggressive gases such as fluorine are used.

If the 972B transducer is located close to a gas source connection like a flow controller or leak valve the transducer pressure measurement can be higher than the actual chamber pressure. Location close to a pumping system connection can cause a lower pressure measurement than actual chamber pressure.

The 972B transducer and its sensor design can be mounted in any orientation without compromising accuracy. **However it is recommended that the transducer not be mounted with the flange port facing upwards to avoid contamination particulates or liquids from entering the device.**


### Explosive Environments

The 972B should not be used in explosive environments, due to its high voltage potential that can cause ignition.

### Temperature

The 972B has an active and individual sensor temperature compensation circuit that ensures accurate measurement in a wide temperature range.

For best measuring performance avoid large temperature gradients and direct cooling like air-condition air stream or direct heating like a pump exhaust stream.



### Bake out

The transducer electronics can withstand 80 °C (176 °F) when the power is turned off.

### Contamination

Locate and orient the 972B where contamination is least likely. The MicroPirani sensor has a low filament temperature of only 35°C above ambient temperature; therefore, the MicroPirani is less prone to contamination by cracking products from fore vacuum pump oil.



If the transducer is backfilled with a liquid (like pump oil) the sensor element is likely permanently damaged. The transducer cannot be cleaned using solvents.

### Vibrations and instant air inrush

The 972B sensor elements are extremely robust to mechanical forces like vibration and G-forces. The sensor element cannot be damaged by fast and repeated pressure cycles or instant inrush of air.

### Vacuum connections

The 972B transducer is available with different types of vacuum fittings. When mounting the transducer always ensure that all vacuum sealing items and surfaces are clean, without damage and free of particles. Do not touch the vacuum flange sealing surface.



If the transducer will be exposed to pressures above atmospheric pressure, make sure that proper vacuum fittings are used. Ensure that the internal system pressure is at ambient pressure conditions before opening the vacuum system and removing any connections.

## Pressure range

The standard 972B transducer is internally sealed with elastomer Viton for use down to  $1 \times 10^{-8}$  Torr. The 972B can be exposed to positive pressure up to 1000 Torr absolute.

## Transducer installation (electrical)

The 972B is available with different input/output connectors. Use a cable with strain relief to ensure proper electrical connection and to reduce stress on the connectors.




**Ensure a low impedance electrical connection between the 972B transducer body and the grounded vacuum system to shield the sensor from external electromagnetic sources.**

**Ensure that the analog output is connected to a floating input.**


Connect a braided cable to the metal hoods at both ends of the cable with the end for power supply connected to Earth ground.

The power supply input is 9 to 30 VDC. The power supply input is protected by an internal thermal fuse. The fuse is self-recoverable; do not replace it. Damage may occur to the circuitry if excessive voltage is applied, polarity reversed or if a wrong connection is made.

If using the analog voltage output, connect the positive analog out and negative analog out pins to a differential input voltmeter or an analog-to-digital (A/D) converter. Do not connect the negative side of the analog output to the negative side of the power supply input or to any other ground. Doing so will cause half of the power current to flow through this wire. Measurement errors in the output voltage may be seen due to the voltage drop from this current. The longer the cable, the worse the error will be. Do not connect the setpoint relay terminals to the analog output.




*Correct connection of analog output to floating input*



*Incorrect connection of analog output to none floating input*


## Input/Output Wiring

### 972B 15 pin I/O Connector RS-232/RS-485




15 pin male HD D-Sub

| PIN | Description                                                |
|-----|------------------------------------------------------------|
| 1   | RS-485- / RS-232 Transmit                                  |
| 2   | RS-485+ / RS-232 Receive                                   |
| 3   | Power + (9-30 VDC)                                         |
| 4   | Power return -                                             |
| 5   | Analog Output +                                            |
| 6   | Analog Output -                                            |
| 7   | Relay 1, Normally Open                                     |
| 8   | Relay 1, Common                                            |
| 9   | Relay 1, Normally Closed                                   |
| 10  | Relay 2, Normally Closed                                   |
| 11  | Relay 2, Common                                            |
| 12  | Relay 2, Normally Open                                     |
| 13  | Relay 3, Normally Closed or Analog Out 2 (Hardware option) |
| 14  | Relay 3, Common                                            |
| 15  | Relay 3, Normally Open                                     |




### 972B EtherCAT 15 pin I/O Connector




15 pin male HD D-Sub

| PIN | Description        |
|-----|--------------------|
| 1   | NC (No Connection) |
| 2   | NC                 |
| 3   | Power + (9-30 VDC) |
| 4   | Power return -     |
| 5   | Analog Output +    |
| 6   | Analog Output -    |
| 7   | NC                 |
| 8   | NC                 |
| 9   | NC                 |
| 10  | NC                 |
| 11  | NC                 |
| 12  | NC                 |
| 13  | NC                 |
| 14  | NC                 |
| 15  | Chassis Ground     |




### EtherCAT I/O Connectors



#### 2 x I/O Connector (8 pin 8P8C): <IN> and <OUT>


| Pin # | Description   | Pin # | Description   |
|-------|---------------|-------|---------------|
| 1     | TX +          | 5     | No Connection |
| 2     | TX -          | 6     | RX -          |
| 3     | RX +          | 7     | No Connection |
| 4     | No Connection | 8     | No Connection |

**972B 9 pin I/O Connector**




9 pin male HD D-Sub


| PIN | Description            |
|-----|------------------------|
| 1   | Relay, Common          |
| 2   | Relay, Normally Open   |
| 3   | Power + (9-30 VDC)     |
| 4   | Power return -         |
| 5   | Analog Output +        |
| 6   | Relay, Normally Closed |
| 7   | RS-232 Transmit        |
| 8   | Analog Output -        |
| 9   | RS-232 Receive         |




**972B I/O Connector  
(6 pin Hirschmann)**




| PIN | Description                                         |
|-----|-----------------------------------------------------|
| 1   | Identification resistor<br>(11K HV OFF, 9K1 HV ON ) |
| 2   | Analog Output +                                     |
| 3   | Analog Output -                                     |
| 4   | Power + (9-30 VDC)                                  |
| 5   | Power return -                                      |
| 6   | Chassis                                             |



**972B I/O Connector  
(8 pin RJ45/FCC68)**




| PIN | Description                 |
|-----|-----------------------------|
| 1   | Power + (9-30 VDC)          |
| 2   | Power return -              |
| 3   | Analog Output +             |
| 4   | Identification resistor (1) |
| 5   | Analog Output -             |
| 6   | Setpoint output             |
| 7   | Not Connected               |
| 8   | Not Connected               |



(1) Identification resistor varies with part number:

| Part number | Value |
|-------------|-------|
| 972B-x1380  | 75K   |
| 972B-x1580  | 85K   |

**972B RS-232 connector  
(6 pin Hirschmann +  
8 pin RJ45/FCC68)**



| PIN | Description     |
|-----|-----------------|
| 1   | RS-232 Transmit |
| 2   | RS-232 Ground   |
| 3   | RS-232 Receive  |
| 4   | RS-232 Receive  |
| 5   | RS-232 Ground   |
| 6   | RS-232 Transmit |

P/N: 10001367 RS-232 Cable for Hirschmann and RJ45/FCC68 Transducers.

## Serial user interface

The 972B is as standard supplied with RS-232 or RS-485 user interface. The user interface allows change of transducer parameters such as setpoint settings and calibration.


The serial interface uses the following data format: 8 data bits, 1 stop bit and no parity bit.

## RS-232 user interface

The 972B is DCE (Data Communication Equipment) and can be connected to DTE (Data Terminal Equipment), typically a PC.

The serial communication does not use hardware handshake. The RS-232 standard does not specify the maximum cable length, but length depends on environment, cable quality and communication speed. In general cable spans shorter than 15m (50ft.) do not require any extra precautions.

The RS-232 connection on transducers delivered with 6 pin Hirschmann and 8 pin RJ45/FCC68 connector is available at a separate connector. Refer to Accessories and Replacement part number page 64 for RS-232 programming cable. The connector is located under the label on the top of the transducer.




## RS-485 user interface

RS-485 is a network communication system that enables the user to communicate with several units on the same communication line.

RS-485 is a balanced communication system, because signal on one wire is ideally the exact opposite of the signal on the second wire. Compared to RS-232 communication RS-485 allows significantly longer cable span. The maximum length of cable span depends on the environment, cable quality and communication speed, but relative long cable spans up to 1,200m (4,000 ft.) is possible.


There are 2 wires other than ground that are used to transmit the digital RS-485 signal. The 972B uses half duplex communication.



**Always use high quality shielded data cables for serial communication. For long cable runs use twisted pairs. See Accessory and Replacement part numbers page 64.**

The EIA-485 and NMEA standards specification states that signal A is the inverting “-“and signal B is the non-inverting or “+”. This conflict with the A/B naming used by different transceiver manufacturers which is incorrect, but their practice is used throughout the industry. Therefore, care must be taken when using A/B naming. In addition to the A and B connections, the EIA standard also specifies a third interconnection point called C, which is the common ground.

At high communication baud rates and when using long cable runs, a termination resistor of typical 120 Ohm should be connected between pin 1 and 2 at the 972B DSUB connector and between pin A and B at the data communication equipment. The termination resistors provides low impedance that reduces the sensitivity to electrical noise and prevents data reflection that can cause data communication corruption.



*RS-485 twisted pair cable run with 120  $\Omega$  terminator resistors (972B with 15 pin connector)*



When connecting multiple devices in a RS-485 network make sure that proper guidelines and specifications are followed to ensure optimal communication performance of the 972B. Improper network design can cause data communication interruption and data collision.

## Communication Protocol


The 972B transducer command set allows the user to change transducer parameters and receive pressure measurements. Settings and parameters like setpoint values, setpoint configurations and calibration data are stored in the transducer's non-volatile memory.

**EtherCAT Communication Protocol:** Refer to the EtherCAT Instruction Manual #20003335, which can be downloaded from the MKS website. Go to [www.mksinst.com](http://www.mksinst.com) and search for 20003335.

## Communication software

Communication software is required to communicate from PC via RS-232/485 interface to the transducer. In the standard Microsoft Windows package, the hyper terminal software can be used to type and transmit serial commands to the transducer. To the right is illustrated the Windows communication port properties for communicating with transducer factory default settings.

MKS also offers communication software examples that can be downloaded at: [www.mksinst.com/vtsw/](http://www.mksinst.com/vtsw/)



In OEM applications transducer communication software routines are normally integrated with other system control software.

## Query and Command Syntax

Queries return current parameter settings; commands change the parameter setting according to the value the user enters into the command syntax. Each query or command must begin with the attention character @ and end with the termination ;FF.

Command syntax for an information query:

@<device address><query>?;FF

Command syntax for a command:

@<device address><command>!<parameter>;FF

The command set allows upper and lower case ASCII characters.

## Response Syntax (ACK/NAK)

The ASCII characters 'ACK' or 'NAK' preface the query or command response string. The ACK sequence signifies the message was processed successfully. The NAK sequence indicates there was an error.

The response to a query or a successful command is:

@<device address>ACK<data>;FF

The response to a message with an error is:

@<device address>NAK<NAK code>;FF

Examples:

ACK response: @253ACK9600;FF (baud rate changed to 9600)

NAK response: @253NAK160;FF (command had an error—possible typo)

The following list provides descriptions of the NAK codes that may be returned.

| NAK Code | Error description                          | Example            |
|----------|--------------------------------------------|--------------------|
| 8        | Zero adjustment at too high pressure       | @253VAC!;FF        |
| 9        | Atmospheric adjustment at too low pressure | @253ATM!7.60;FF    |
| 160      | Unrecognized message                       | @253S%;FF          |
| 169      | Invalid argument                           | @253EN1!of;FF      |
| 172      | Value out of range                         | @253SP1!5.00E+9;FF |
| 175      | Command/query character invalid            | @253FV!;FF         |
| 180      | Protected setting (locked)                 | -                  |
| 195      | Control setpoint enabled (ENC)             | @253FP!ON;FF       |

---

**Baud rate** *(not available in EtherCAT units)*

The baud rate represents the communication speed. The 972B supports 4800, 9600, 19200, 38400, 57600, 115200 and 230400 baud rates. The transducer is always delivered with 9600 bps factory default baud rate.

Change of Baud rate:

|                  |                                                 |
|------------------|-------------------------------------------------|
| Command:         | @253BR!19200;FF                                 |
| Command values:  | 4800, 9600, 19200, 38400, 57600, 115200, 230400 |
| Command reply:   | @253ACK19200;FF                                 |
| Factory default: | 9600                                            |

The transducer will reply in the current baud rate and then change to the new value.

**Addressing** *(not available in EtherCAT units)*

The transducer uses an addressable communication protocol that allows multiple MKS 900 Series transducer devices to be connected in a RS-485 network. The address is required in both RS-232 and RS-485 communication. The address can be set from 001 to 253. Address 254 and 255 are universal addresses, which can be used to broadcast a command to all devices on the network. Commands sent with address 254 will be executed by all transducers on the network and all transducers will transmit a reply. Commands sent with address 255 will be executed by all transducers on the network, but the transducers will not transmit replies. For example, use address 254 to communicate with a device if its address is unknown.

Change of Address:

|                  |               |
|------------------|---------------|
| Command:         | @253AD!123;FF |
| Command values:  | 001 to 253    |
| Command reply:   | @253ACK123;FF |
| Query:           | @254AD?;FF    |
| Query reply:     | @253ACK253;FF |
| Factory default: | 253           |

**Communication delay (RS-485)** *(not available in EtherCAT units)*

The 972B half-duplex RS-485 interface requires that data is transmitted and received on the same communication line. Some RS-485 transceiver equipment have a settling time when changing from transmit to receive mode. If the transducer replies too fast the first character(s) will not be received as the following example illustrates:

|                           |                                            |
|---------------------------|--------------------------------------------|
| Sending pressure request: | @254PR1?;FF                                |
| Receiving data:           | 23E-4;FF (Correct data: @253ACK1.23E-4;FF) |

The RS delay introduces a baud rate dependent delay between receive and transmit sequence to prevent loss of data in the receiving string.

Communication delay:

|                  |               |
|------------------|---------------|
| Command:         | @253RSD!ON;FF |
| Command values:  | ON, OFF       |
| Command reply:   | @253ACKON;FF  |
| Query:           | @253RSD?;FF   |
| Query reply:     | @253ACKON;FF  |
| Factory default: | ON            |

### Setpoint relays (not available in EtherCAT units)

The 972B can be ordered with 3 mechanical relays that can be used to control external process equipment. The relay has closing and breaking contacts and the contacts are rated 30 VDC, 1A resistive load.

If the transducer is supplied without setpoint relays, the setpoint commands can still be accessed. Refer to part number definition on page 3 to verify if setpoint relays are included.

### Inductive relay load

Special precautions should be taken when driving inductive loads at the relay contact. When an inductive load like a solenoid is energized, the in-rush current is significantly higher than the regular load current. In-rush currents exceeding the relay contact rating can cause reduction of relay contact life time or contact reliability.

When a solenoid is de-energized, the collapsing magnetic field can cause significant voltage spikes. These spikes can couple capacitively from cable to cable and interfere with measuring electronics or transducer signal.



**Driving inductive loads via the setpoint relay contacts requires de-energizing spike protection. Inadequate protection can cause permanent damage to the transducer or interfere with the analog output signal.**

**Always ensure that inductive inrush currents do not exceed relay contact rating.**

An arc suppression network as shown schematically to the right is recommended. The values of the capacitance C and the resistance R can be calculated by the following equations:


$$C = I^2 / (1 \times 10^7) \quad R = E / I^a$$

where:

C is in Farad. R is in Ohm

I is DC or AC<sub>peak</sub> load current in Ampere. E is DC or AC<sub>peak</sub> source voltage in Volt

$$a = 1 + (50/E)$$



Note that  $R_{min} = 0.5 \Omega$  and  $C_{min} = 1 \times 10^{-9} F$ . D is a fast-transient suppression diode.

### PDR900 controller relays (not available in EtherCAT units)



The PDR900 controller has power relays that can drive higher current loads and voltages than the transducer relays. If the transducer is used with the PDR900 controller refer to PDR900 manual for setup of relay output.



**Do not connect any external sources to the transducer relay pins when using it together with the PDR900 controller. Always use the PDR900 relay outputs.**

### Setpoint functionality

The setpoint relays can be activated either above or below the setpoint values. The graphs below show the different relays stages in either below or above configuration. The NC contact will always be closed in case of power failure.





**When using the setpoint relay to control process equipment, always take appropriate precautions to prevent system damage in case of transducer power failure. The NC contact will be closed in case of transducer power failure.**



If the transducer is supplied as a special version (P/N: 972B-xxxx-xxxx) with pre-configured parameters such as setpoint settings, the setup is per default locked. The transducer will reply with error code "NAK180" if the user tries to change parameters. To change pre-configured parameters, refer to unlock procedure page 27.

### Setpoint setup by Serial interface

The correct procedure for setting up setpoint parameters are:

1. Enter setpoint value 5.00E+1 Torr  
Command: @253SP1!5.00E+1;FF Reply: @253ACK5.00E+1;FF
2. Select setpoint direction (ABOVE/BELOW)  
Command: @253SD1!BELOW;FF Reply: @253ACKBELOW;FF
3. Enter setpoint hysteresis value, if other than default +/- 10% of setpoint value is required.  
Command: @253SH1!4.00E+1;FF Reply: @253ACK4.00E+1;FF
4. Enable setpoint (OFF, CMB, PIR, CC)  
Command: @253EN1!CC;FF Reply: @253ACKCC;FF

### Setpoint setup by PDR900 Controller

- |                                                                                                                                                       |                                 |
|-------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|
| 1. Edit > Setpoint > Setpoint 1> Setpoint Value 1<br>Enter setpoint value 5.00E+1 Torr                                                                | Enter pressure<br>+5.00E+1 Torr |
| 2. Edit > Setpoint > Setpoint 1> Direction 1<br>Select setpoint direction                                                                             | Direction 1<br>BELOW            |
| 3. Edit > Setpoint > Setpoint 1> Hysteresis 1<br>Enter setpoint hysteresis value<br>Only if other than default +/- 10% of setpoint value is required. | Enter pressure<br>+6.00E+1 Torr |
| 4. Edit > Setpoint > Setpoint 1> Enable 1<br>Enable setpoint                                                                                          | Enable 1<br>CMB                 |

### Setpoint value

The setpoint value is the pressure either below or above which the setpoint relay will be energized.

### Setpoint hysteresis value

The hysteresis value is the pressure value at which the setpoint relay will be de-energized.

### Setpoint direction

The setpoint direction determines whether the relay is energized above or below the setpoint value.

### Enable setpoint

The enable setpoint command enables, disables or assigns the setpoint relay to either the combined reading (CMB), the Cold Cathode (CC) or MicroPirani measurement (PIR).



**The 972B transducer has an auto hysteresis setting of 10% of the setpoint value that overwrites the current hysteresis value whenever the setpoint value or setpoint direction is changed. If other hysteresis value than 10% is required, first set the setpoint value and setpoint direction before setting hysteresis value.**

## Setpoint safety delay (not available in EtherCAT units)

The setpoint safety delay function requires 5 continuously measurements that exceeds setpoint value before the relay is tripped. This feature prevents that noise or pressure pulse can trig the relay. If fast setpoint response is required, the setpoint safety delay can be disabled.


### Setpoint safety delay:

Command: @253SPD!ON;FF  
 Command values: ON, OFF

Command reply: @253ACKON;FF  
 Query: @253SPD?;FF  
 Query reply: @253ACKON;FF  
 Factory default: ON

## Integrated Touch Display (not available in EtherCAT units)

For 972B transducer versions with integrated touch display it is possible to see information about setpoints, sensors, model, and measurements unit. A pressure threshold alarm can be set and for transmitters with multiple sensors. It is possible to choose which sensor pressure value is displayed on the screen. All of this is accessible by the following menu structure:



### Using the integrated touch display:

When the transducer is turned on, the initializing screen shows the transducer name while starting up. After start-up, the screen automatically switches to the Main screen. To access the Menu, push anywhere on the Main screen. The following table shows the different menus and options available:

| Display-screen  | Information                                                                                                                                                                                                                                                                                                                                         |                                                            |                            |                                  |
|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------|----------------------------|----------------------------------|
| Start-up        | MKS logo and transducer model                                                                                                                                                                                                                                                                                                                       |                                                            |                            |                                  |
| Home            | The Home screen shows the current pressure, the transducer model, the status of the setpoints, the triggering direction of each setpoint and shows if an alarm is enabled.<br>The setpoint buttons and unit text give quick access to the separate Setpoint-screens and Unit screen respectively.                                                   |                                                            |                            |                                  |
| Menu            | The general Menu contains 4 buttons which lead to:<br>Settings, Sensor, Setpoints menu and Home.                                                                                                                                                                                                                                                    |                                                            |                            |                                  |
| Settings        | The Settings menu contains 4 buttons which lead to:<br>Model info, Setup menu, Unit and Back                                                                                                                                                                                                                                                        |                                                            |                            |                                  |
| Setup           | The Setup menu contains 3 buttons which lead to:<br>Screen rotation, Alarm and Back                                                                                                                                                                                                                                                                 |                                                            |                            |                                  |
| Sensor          | The Sensor screen shows which sensor's measurement is displayed on the Home screen (green marked sensor).                                                                                                                                                                                                                                           |                                                            |                            |                                  |
| Setpoints menu  | The Setpoint menu contains 4 buttons which lead to:<br>Setpoint 1, Setpoint 2, Setpoint 3 and Back (to Menu)                                                                                                                                                                                                                                        |                                                            |                            |                                  |
| Setpoint screen | Setpoint 1,2 or 3                                                                                                                                                                                                                                                                                                                                   |                                                            |                            |                                  |
|                 | Each Setpoint screen shows the setpoint status, the pressure unit, pressure triggering direction, setpoint value and hysteresis value.                                                                                                                                                                                                              |                                                            |                            |                                  |
|                 | The setpoint status is indicated by:                                                                                                                                                                                                                                                                                                                |                                                            |                            |                                  |
|                 | X                                                                                                                                                                                                                                                                                                                                                   | Setpoint disabled (Grey)                                   |                            |                                  |
|                 | PIR                                                                                                                                                                                                                                                                                                                                                 | Setpoint enabled ON/OFF, MEMS-Pirani dependent (Green/Red) |                            |                                  |
| PZ              | Setpoint enabled ON/OFF, Piezo dependent (Green/Red)                                                                                                                                                                                                                                                                                                |                                                            |                            |                                  |
| CMB             | Setpoint enabled ON/OFF, Combined sensor dependent (Green/Red)                                                                                                                                                                                                                                                                                      |                                                            |                            |                                  |
|                 | If the Setpoint screen is accessed via the Setpoint menu, pressing the screen will lead back to the same menu. If accessed via the quick-access buttons on the Main screen, pressing the screen will lead back to the Main screen.                                                                                                                  |                                                            |                            |                                  |
| Model info      | The Model info screen shows the transducer type and model number and each screen has different extra information. Press the screen to toggle through the different info screens and eventually go back to Settings.                                                                                                                                 |                                                            |                            |                                  |
|                 | Model info (1/4)                                                                                                                                                                                                                                                                                                                                    | Model info (2/4)                                           | Model info (3/4)           | Model info (3/4)                 |
|                 | Transducer P/N                                                                                                                                                                                                                                                                                                                                      | Gas type                                                   | Interface type             | User switch ON/OFF               |
|                 | Serial number                                                                                                                                                                                                                                                                                                                                       | Transducer firmware version                                | Connector type             | Setpoint delay 50ms ON/OFF       |
|                 | User tag                                                                                                                                                                                                                                                                                                                                            | Display firmware version                                   | Number of available relays | Relay communication delay ON/OFF |
|                 | Communication address                                                                                                                                                                                                                                                                                                                               | RS-485 testing                                             |                            | Temperature (°C)                 |
|                 | Baud rate                                                                                                                                                                                                                                                                                                                                           | Pressure unit<br>Transducer ON-time                        |                            |                                  |
| Unit            | The Unit screen displays the current pressure unit and gives the possibility to change the pressure unit between Torr, Millibar or Pascal.                                                                                                                                                                                                          |                                                            |                            |                                  |
| Screen rotation | The Screen Rotation screen displays the current screen orientation and enables the operator to rotate the screen in four directions.                                                                                                                                                                                                                |                                                            |                            |                                  |
| Alarm           | A visual alarm can be set at a certain pressure.<br>Press the green or red button to enable or disable the alarm.<br>Press Set to change the alarm pressure value and triggering direction.                                                                                                                                                         |                                                            |                            |                                  |
|                 | Set Alarm (1/2)                                                                                                                                                                                                                                                                                                                                     |                                                            |                            |                                  |
|                 | Setting pressure threshold:<br>The alarm value is set by selecting a digit (left and right arrow) and cycling through the numbers 0-9 and +/- (press up arrow or screen)<br>To accept, press right arrow until a green checkmark appears. Press again to proceed.<br>To cancel, press left arrow until a red arrow appears. Press again to proceed. |                                                            |                            |                                  |
|                 | Set Alarm (2/2)                                                                                                                                                                                                                                                                                                                                     |                                                            |                            |                                  |
|                 | When the alarm is set, the operator selects whether the alarm triggers above or below the given value.                                                                                                                                                                                                                                              |                                                            |                            |                                  |

## Pressure output

The 972B transducer can provide pressure measurement output as an analog voltage or RS-232/RS-485 digital value. The digital value is 3 digits scientific notation for PR1, PR3, PR5 reading and 4 digits for PR4 reading.

*NOTE: For EtherCAT units, see the EtherCAT Communication Protocol instruction manual #20003335.*

Pressure request:

Query: @253PR1?;FF  
Query reply: @253ACK1.23E-4;FF

Pressure outputs:

PR1: MicroPirani sensor reading  
PR2: Cold Cathode reading (same as PR5)  
PR3: MicroPirani and Cold Cathode combined reading  
PR4: MicroPirani and Cold Cathode combined reading (4 digits)  
PR5: Cold Cathode reading

The default analog output is based on the combined PR3 reading and provides a 16 bit voltage output of 0.5 VDC/decade standard configurations. Refer to Analog output on page 29 for details.




**If ionization does not ignite the combined output will provide the MicroPirani measurement until valid ignition is detected.**


### Combined reading PR3 and PR4

The PR3, PR4 and the analog output combines the Cold Cathode reading and the MicroPirani reading into one smooth pressure reading with accurate measuring performance throughout the entire pressure range of 11 decades.

The MicroPirani automatically turn on the Cold Cathode at  $5E-4$  Torr (SLC) and turn it off at  $8E-4$  Torr (SHC). Above  $4E-4$  the combined reading is the MicroPirani pressure measurement and below  $1E-4$  Torr it is the Cold Cathode pressure measurement. Between  $1E-4$  and  $4E-4$  Torr the two measurements are smoothly integrated. The PR3 reading provides 3 digits resolution and the PR4 reading provides 4 digits resolution.



SLC: Low CC turn on pressure ( $5.0E-4$  Torr)  
SHC: High CC turn off pressure ( $8.0E-4$  Torr)  
SLP, Low CC/MP integration ( $1.0E-4$  Torr)  
SHP, High CC/MP integration ( $4.0E-4$  Torr)



In some application it is preferred not to have the Cold Cathode (high voltage) turned on during vacuum process or during mass spectrometer analyzing. The 972B Cold cathode turn on pressure (SLC) and turn off pressure (SHC) can be changed by the user. Furthermore, the high and low integration levels between the Cold Cathode reading and MicroPirani reading can be changed by the user.



When designing pressure data collecting software and controlling loop, make sure the software does not interpret a communication error as a valid pressure value.

---

### Cold Cathode ignition startup

When the Cold Cathode high voltage is enabled, automatically by the MicroPirani or manually, an ignition delay may occur. The ignition waiting time is from less than a second at high pressures to minutes at low pressures. The ignition time is a function of gas density, cleanness of the gauge and presence of any other ion sources in the system.

The combined analog output and PR3, PR4 reading provides the MicroPirani reading until ignition has occurred and valid Cold Cathode measurements is present. When the Cold Cathode is enabled, but ionization not ignited the LED will flash red. The LED will flash green when valid measurements are present.

| Pressure     | Typical ignition time |
|--------------|-----------------------|
| 1.00E-8 Torr | ≈12 Minutes           |
| 1.00E-6 Torr | ≈10 Seconds           |
| 1.00E-4 Torr | ≈1 Second             |

### Resolution

The digital pressure output can provide 3 digit or 4 digit values; however, the resolution is limited in certain parts of the measuring range.

| MicroPirani:            |                          |          |
|-------------------------|--------------------------|----------|
| 1.00E-5 to 1.00E-4 Torr | 1 digit resolution       | 1.000E-5 |
| 1.00E-4 to 1.00E-3 Torr | 2 digits resolution      | 1.200E-4 |
| 1.00E-3 to 900 Torr     | 3 or 4 digits resolution | 1.234E-3 |
| Cold Cathode:           |                          |          |
| 1.00E-7 to 1.00E-8 Torr | 2 digits resolution      | 1.50E-8  |
| 5.00E-3 to 1.00E-7 Torr | 3 digits resolution      | 1.230E-4 |

### Measuring noise

External sources can interfere with the sensor signal and cause noise in the signal. The low measuring range is most sensitive to measuring noise due to low signal levels.

### Magnetic interference

External magnetic sources can interfere with the Cold Cathode sensor and cause measurement deviation from actual pressure. Avoid having magnetic material located close to the 972B Transducer.

### Cold Cathode pressure dose *(not available in EtherCAT units)*

The Cold Cathode pressure dose continuously monitors the Cold Cathode time on as function of the pressure. If the cold cathode is on for 100 hours at 1E-4 Torr the pressure dose is  $100 \times 1E-4 = 1E-2$  Torr hours. The pressure dose readout can be used to determine the time interval between Cold Cathode maintenance and service.

Pressure dose request:

Query: @253TIM3?;FF  
Query reply: @253ACK1.23E-4;FF



The pressure dose reading is only a rough indication of the cold cathode status. When the cold cathode is contaminated the sensitivity of the gauge is decreased and it will provide a lower reading than actual pressure. Therefore the calculated pressure dose can be lower than the actual pressure dose.

### Cold Cathode pressure dose setpoint *(not available in EtherCAT units)*

The Cold Cathode pressure dose setpoint provides an indication when a defined pressure dose is exceeded. The transducer status query will provide "R" when pressure dose is exceeded.

Pressure dose setpoint command:


Command: @253PD!1.00E-2;FF  
Command values: 1.00E-6 to 100  
  
Command reply: @253ACK1.00E-2;FF  
Query: @253PD?;FF  
Query reply: @253ACK1.00E-2;FF  
Factory default: 1.00E+00 Torr  
Value out of range: @253NAK172;FF

## Cold Cathode setup

The 972B can be configured to the process and application by individually programming of the cold cathode turn on and off pressure and pressure settings for MicroPirani integration.

### Cold cathode auto turn on and off

The 972B has a control setpoint for turning the cold cathode on and off. The SLC command sets the turn on pressure and SHC command sets the turn off pressure.



If the Cold Cathode control setpoint is disabled, the sensor control must be executed manually with the FP command. Operation of the cold cathode at higher pressure than 1E-3 Torr can cause loss of measurement performance.

If the SLC and SHC value are too close the Cold Cathode can turn off immediately after turning on.

### Cold cathode turn on pressure (Only if ENC is ON) *(not available in EtherCAT units)*

Command: @253SLC!1.00E-4;FF  
Command values: 1.00E-4 to 5.00E-3

Command reply: @253ACK1.00E-4;FF  
Query: @253SLC?;FF  
Query reply: @253ACK5.00E-4;FF  
Factory default: 5.00E-4 Torr  
Value out of range: @253NAK172;FF


### Cold cathode turn off pressure (Only if ENC is ON) *(not available in EtherCAT units)*

Command: @253SHC!8.00E-4;FF  
Command values: >SLC (turn on pressure) or 1.00E-4 to 5.00E-3

Command reply: @253ACK8.00E-4;FF  
Query: @253SHP?;FF  
Query reply: @253ACK8.00E-4;FF  
Factory default: 8.00E-4 Torr  
Value out of range: @253NAK172;FF

### Cold cathode / MicroPirani smoothing

The combined output (PR3) switches automatically between the MicroPirani and Cold Cathode sensor. The high and low switch value can be set and should correspond to the cold cathode turn on and off pressure.



### Sensor smoothing low value

Command: @253SLP!1.00E-4;FF  
Command values: 1.00E-4 to SHP (turn off pressure)

Command reply: @253ACK1.00E-4;FF  
Query: @253SLP?;FF  
Query reply: @253ACK1.00E-4;FF  
Factory default: 1.00E-4 Torr  
Value out of range: @253NAK172;FF

When setting the turn on value, the turn off value is automatically set to 30% higher than the low value.

---

### Sensor smoothing high value *(See the EtherCAT Communication Protocol Manual #20003335)*

Command: @253SHP!8.00E-4;FF  
Command values: 1.00E-4 to 5.00E-3  
  
Command reply: @253ACK8.00E-4;FF  
Query: @253SHP?;FF  
Query reply: @253ACK4.00E-4;FF  
Factory default: 4.00E-4 Torr  
Value out of range: @253NAK172;FF

### Cold Cathode control setpoint *(not available in EtherCAT units)*

The Cold Cathode control setpoint automatically turn on the Cold Cathode high voltage when the MicroPirani pressure is lower than the SLC value.

Command: @253ENC!ON;FF  
Command values: ON, OFF  
  
Command reply: @253ACKON;FF  
Query: @253ENC?;FF  
Query reply: @253ACKON;FF  
Factory default: ON

### Cold Cathode protect setpoint *(not available in EtherCAT units)*

The Cold Cathode protect setpoint automatically turns off the Cold Cathode high voltage if the cold cathode measurement exceeds 5.00E-3 Torr for 120 seconds. The protect setpoint can be turned off (disabled) or time set between 0 and 999 seconds.

Command: @253PRO!ON;FF  
Command values: ON (120), OFF, 0 to 999 seconds  
  
Command reply: @253ACK120;FF  
Query: @253PRO?;FF  
Query reply: @253ACK120;FF  
Factory default: OFF

### Cold Cathode power *(See the EtherCAT Communication Protocol Manual #20003335)*

If the Cold Cathode control setpoint is disabled (OFF) then the Cold Cathode high voltage can be manually controlled by the FP command.

Command: @253FP!ON;FF  
Command values: ON, OFF  
  
Command reply: @253ACKON;FF  
Query: @253FP?;FF  
Query reply: @253ACKOFF;FF  
Factory default: OFF  
ENC is ON: @253NAK195;FF

If Cold Cathode control setpoint (ENC) is on, the Cold Cathode power cannot be controlled manually.

### Cold Cathode pressure dose *(not available in EtherCAT units)*

The Cold Cathode pressure dose continuously monitors the Cold Cathode time on as function of the pressure. If the cold cathode is on for 100 hours at 1E-4 Torr the pressure dose is  $100 \times 1E-4 = 1E-2$  Torr hours. The pressure dose readout can be used to determine the time interval between Cold Cathode maintenance and service.

Pressure dose request:  
Query: @253TIM3?;FF  
Query reply: @253ACK1.23E-4;FF

---

## Calibration and adjustment

The 972B is factory calibrated when delivered and in many applications further calibration is not required. If the sensor element has been contaminated or damaged by process gases, adjustment of zero and full scale can be executed to compensate for small measurement errors.

If operated in oil lubricated pumping systems or other none clean environments the cold cathode reading changes over time. The cold cathode reading can be adjusted, or the sensor anode can be replaced or cleaned. Refer to Service and Repair page 62.



**The 972B is calibrated at the factory for reading Nitrogen gas. When exposed to atmospheric air the MicroPirani sensor (PR1) will read higher values, typically 900 Torr at ambient pressure.**

## Accuracy and repeatability

The 972B measuring accuracy is specified as transducer reading  $\pm$  a percentage of the actual pressure. The basic measuring accuracy is factory calibrated and cannot be user adjusted. The repeatability specification is the transducers ability to repeat the same measurement value after multiple pressure cycles. Refer to the transducer specification page 60 for actual values.

## Gas calibration

The 972B is based on measurement of thermal conductivity and ionization of the gas and consequently its reading depends on the gas type and concentration. The factory default setting is Nitrogen calibration; however, the transducer has MicroPirani calibration curves for several common gases.

*NOTE: For EtherCAT units, see the EtherCAT Communication Protocol instruction manual #20003335.*

Change of gas calibration setup:

|                  |                                                               |
|------------------|---------------------------------------------------------------|
| Command:         | @253GT!ARGON;FF                                               |
| Command values:  | NITROGEN, AIR, ARGON, HELIUM, HYDROGEN, H2O, NEON, CO2, XENON |
| Command reply:   | @253ACKARGON;FF                                               |
| Query:           | @253GT?;FF                                                    |
| Query reply:     | @253ACKARGON;FF                                               |
| Factory default: | NITROGEN                                                      |

The cold cathode gas Nitrogen calibration does not change with the GT command.

## Pressure unit calibration

The transducer can provide digital and analog output in Torr, mbar and Pascal pressure units. When changing pressure unit all parameters such as setpoint settings are automatically converted to the new unit, so it will represent the same pressure level. All pressure parameters such as setpoint settings and calibration values must be entered in the actual transducer unit setting.

*NOTE: For EtherCAT units, see the EtherCAT Communication Protocol instruction manual #20003335.*

Change of pressure unit calibration setup:

|                  |                    |
|------------------|--------------------|
| Command:         | @253U!PASCAL;FF    |
| Command values:  | TORR, MBAR, PASCAL |
| Command reply:   | @253ACKPASCAL;FF   |
| Query:           | @253U?;FF          |
| Query reply:     | @253ACKTORR;FF     |
| Factory default: | TORR               |

The Torr unit is most common in the US and mbar is most common in Europe. Pascal is the official pressure unit as specified by SI (from the French *Le Système International d'Unités*) and is widely used in Asia.

---

### MicroPirani™ Auto Zero limit Adjustment (MZL) (not available in EtherCAT units)

The MicroPirani will be zero adjusted whenever the pressure measured by the Cold Cathode is lower than 8E-6 Torr (MZL). For applications that do not go below 8E-6 Torr the MicroPirani auto zero limit can be set to higher pressure.

Change of pressure auto zero limit:

Command: @253MZL!1.00E-4;FF  
Command values: 1.00E-6 to 5.00E-4  
  
Command reply: @253ACK1.00E-4;FF  
Query: @253MZL?;FF  
Query reply: @253ACK1.00E-4;FF  
Reset to default: @253FD!MZL;FF  
Factory default: 1.00E-4 Torr  
Value out of range: @253NAK172;FF

### MicroPirani Zero Adjustment by serial interface

The zero adjustment function changes the MicroPirani measurement offset at low pressure. Temporary or permanent shift in zero offset can be caused by contamination, corrosion, electrical noise interference and temperature.



**Zero adjustment only changes the low measuring range and will have no influence on measuring errors in the range from  $1 \times 10^{-2}$  and above.**

If the transducer is reading 8.00E-5 Torr at an actual pressure of 1.00E-5 Torr, the offset error is +7.00E-5 or 700% error of actual pressure. At two decades higher pressure of 1.00E-3 Torr the same offset error is a factor 100 lower. At 1.00E-3 Torr an offset error of 7.00E-5 Torr is equivalent to a 7% error.



**To obtain best measuring performance, the transducer should be evacuated to a pressure below  $8 \times 10^{-6}$  Torr before executing zero adjustment. Zero adjustment can be executed at higher pressures, but this can cause inaccurate reading below the zero adjustment value.**

Executing zero adjustment. (Evacuate the transducer to a pressure below  $8 \times 10^{-6}$  Torr or enter the zero pressure)  
*NOTE: For EtherCAT units, see the EtherCAT Communication Protocol instruction manual #20003335.*

Command: @253VAC!5.00E-5;FF  
Command values: None, < 3.00E-3  
  
Command reply: @253ACK;FF  
Query: @253VAC?;FF  
Query reply: @253ACK0.00+00;FF  
Reset to default: @253FD!VAC;FF  
Factory default: *Factory adjustment value*  
Value out of range: @253NAK172;FF

After execution of zero adjustment the PR1 reading will be  $1 \times 10^{-5}$  Torr. If the pressure measured by the transducer is higher than approximately  $1 \times 10^{-2}$  Torr then the zero adjustment cannot be executed. This indicates that the transducer is contaminated and should be serviced. See page 53 for Service and Repair procedures.

The query feature reads the delta value between the user offset value and factory default value. This can be used to monitor the positive and negative offset trend regardless of how many times the zero adjustment is executed.

### Zero Adjustment by use of the User switch (not available on EtherCAT units)

The transducer can also be adjusted by activating the user switch. When using the switch, the transducer must be evacuated to a pressure below  $8 \times 10^{-6}$  Torr. Press down the switch for 2 seconds and the LED will flash green three times to acknowledge the zero adjustment has been executed successfully. The LED will flash red three times if the adjustment has failed.

---

### MicroPirani Atmospheric adjustment (See the EtherCAT Communication Protocol Manual #20003335)

The MicroPirani atmospheric adjustment allows the user to adjust the MicroPirani full scale reading. Vent the transducer to atmospheric pressure using the gas that corresponds to the gas calibration setup. Atmospheric adjustment can only be executed with air or Nitrogen.



**Atmospheric adjustment only changes the high measuring range and will have no influence on measuring errors in the range below 10 Torr.**

Executing atmospheric adjustment. (Vent the transducer to Nitrogen or air pressure of 500-780 Torr)

Command: @253ATM!7.60E+2;FF  
Command values: 4.00E+2 to 8.00E+2  
  
Command reply: @253ACK7.60E+2;FF  
Query: @253ATM?;FF  
Query reply: @253ACK0.00E+0;FF  
Reset to default: @FD!ATM;FF  
Factory default: *Factory adjustment value*

The query feature reads the delta value between the user atmospheric adjustment value and the factory default value.

### Cold cathode zero adjustment (See the EtherCAT Communication Protocol Manual #20003335)

The Cold Cathode zero adjustment allows the user to adjust the cold cathode zero reading.

Executing zero adjustment

Evacuate the transducer to a base pressure below  $1 \times 10^{-6}$  Torr or enter the zero pressure by use of a calibrated reference gauge.

To obtain measuring performance the transducer should be evacuated to pressure below  $5 \times 10^{-8}$  Torr.



If the Cold Cathode zero adjustment is executed at high pressure, the measurement below the zero value can become unreliable. Always zero at the system base pressure.

Command: @253VAC3!2.00E-8;FF  
Command values: 1.00E-6 to 1.00E-8 Torr  
  
Command reply: @253ACK;FF  
Query: @253VAC3?;FF  
Query reply: @253ACK0.00+00;FF  
Reset to default: @253FD!VAC3;FF  
Factory default: *Factory adjustment value*  
Value out off range: @253NAK172;FF

### Cold cathode full scale adjustment

The Cold Cathode full scale adjustment allows the user to adjust the cold cathode reading at high pressure.

Command: @253CFS!4.00E-3;FF  
Command values: 1.00E-4 to 5.00E-3 Torr  
  
Command reply: @253ACK;FF  
Query: @253CFS?;FF  
Query reply: @253ACK5.00E-3;FF  
Reset to default: @253FD!CFS;FF  
Factory default: *Factory adjustment value*  
Value out off range: @253NAK172;FF

## Factory defaults

(See the EtherCAT Communication Protocol Manual #20003335)

The transducer is per factory default delivered with parameters and setup as listed below. If the transducer is delivered with customer preconfigured parameters the values are different than listed below and the parameters will be locked per default.

### Communication parameters:

| Description          | Command | Parameter | FD! | FD!ALL |
|----------------------|---------|-----------|-----|--------|
| Address:             | AD!     | 253       | -   | x      |
| Baud rate:           | BR!     | 9600      | -   | x      |
| Communication delay: | RSD!    | ON        | -   | x      |

### Transducer parameters:

| Description                    | Command | Parameter         | FD! | FD!ALL |
|--------------------------------|---------|-------------------|-----|--------|
| Test mode (LED flash):         | TST!    | OFF               | x   | x      |
| User tag:                      | UT!     | MKS               | -   | x      |
| Setpoint 1 value:              | SP1!    | 1.00E0            | -   | x      |
| Setpoint 1 hysteresis value:   | SH1!    | 1.10E0            | -   | x      |
| Setpoint 1 direction:          | SD1!    | BELOW             | -   | x      |
| Setpoint 1 enable:             | EN1!    | OFF               | -   | x      |
| Setpoint 2 value:              | SP1!    | 1.00E0            | -   | x      |
| Setpoint 2 hysteresis value:   | SH1!    | 1.10E0            | -   | x      |
| Setpoint 2 direction:          | SD1!    | BELOW             | -   | x      |
| Setpoint 2 enable:             | EN1!    | OFF               | -   | x      |
| Setpoint 3 value:              | SP1!    | 1.00E0            | -   | x      |
| Setpoint 3 hysteresis value:   | SH1!    | 1.10E0            | -   | x      |
| Setpoint 3 direction:          | SD1!    | BELOW             | -   | x      |
| Setpoint 3 enable:             | EN1!    | OFF               | -   | x      |
| Switch enable:                 | SW!     | ON                | -   | x      |
| Analog out 1:                  | AO1!    | 30 <sup>(1)</sup> | -   | x      |
| Analog out 2:                  | AO2!    | 30                | -   | x      |
| Cold Cathode turn on setpoint  | SLC!    | 5.00E-4           | -   | x      |
| Cold Cathode turn off setpoint | SHC!    | 8.00E-4           | -   | x      |
| Cold Cathode control setpoint  | ENC!    | ON                | -   | x      |
| Cold Cathode protect setpoint  | PRO!    | OFF               | -   | x      |
| MP/CC Smoothing low limit      | SLP!    | 1.00E-4           | -   | x      |
| MP/CC Smoothing high limit     | SHP!    | 4.00E-4           | -   | x      |
| MicroPirani auto Zero limit    | MZL!    | 1.00E-4           | x   | x      |

(1) If the transducer is delivered with other analog output than standard mks (part number specified), then the factory default value will be specified by the specials part number.

### Calibration setup:

| Description                     | Command | Parameter                       | FD! | FD!ALL |
|---------------------------------|---------|---------------------------------|-----|--------|
| Gas calibration:                | GT!     | NITROGEN                        | x   | x      |
| MP Vacuum adjustment:           | VAC!    | <i>Factory adjustment value</i> | x   | x      |
| MP Span atmospheric adjustment: | ATM!    | <i>Factory adjustment value</i> | x   | x      |
| CC Vacuum adjustment:           | VAC3!   | <i>Factory adjustment value</i> | x   | x      |
| CC full scale adjustment:       | CFS!    | <i>Factory adjustment value</i> | x   | x      |
| Pressure unit:                  | U!      | TORR                            | -   | x      |

### Resetting to factory default

The factory default command resets all or certain parameters of the 972B to factory default settings as listed above. If other digital communication setup than factory default values are used, then the communication will be lost after execution of factory default and the transceiver equipment should be set to transducer values.



**The factory default command resets parameters to default values and consequently user adjustments, setup and factory configured parameters are lost. Use with caution!**

Command: @253FD!ALL;FF  
 Command values: None, ALL, UNLOCK, LOCK, VAC, VAC3, ATM, CFS  
 Command reply: @253ACKFD;FF

---

## Transducer lock function (*not available on EtherCAT units*)

To ensure that unauthorized personnel are not able to change transducer setup and parameters, the transducer lock function can prevent direct access to parameter changes. Transducers delivered with pre-configured custom specified parameters (special part number) are per default locked and will reply with “NAK180”, if the user tries to change locked parameters. The unlock procedure must be executed to change these parameters.

### Disable lock function command:

Command: @253FD!UNLOCK;FF  
Command reply: @253ACKFD;FF

### Enable lock function command:

Command: @253FD!LOCK;FF  
Command reply: @253ACKFD;FF

Standard transducer (7 digits part number: 972B-xxxx)  
Factory default: *Transducer unlocked*

Special configuration transducer (11 digits part number: 972B-xxxx-xxxx)  
Factory default: *Transducer locked*



**If the transducer is delivered with special configuration, the lock function will only be temporarily disabled and will be enabled again after cycling power cycle or executing the enable lock command.**



**The 972B transducer can be delivered with factory locked tamperproof settings for safety interlock applications. This option is defined in the special settings. If delivered with factory lock the transducer settings can only be changed by return of gauge to MKS.**

## User Switch Command (*not available on EtherCAT units*)

The User Switch function can be disabled to prevent accidental execution of zero and atmospheric adjustments.

Command: @253SW!OFF;FF  
Command values: ON,OFF

Command reply: @253ACKOFF;FF  
Query: @253SW?;FF  
Query reply: @253ACKON;FF  
Factory default: ON

## Transducer test (not available on EtherCAT units)

The transducer test command can be used to visually identify a transducer. If the test mode is enabled the LED will flash with a 1 sec. cycle.

Command: @253TST!ON;FF  
Command values: ON,OFF

Command reply: @253ACKON;FF  
Query: @253TST?;FF  
Query reply: @253ACKON;FF  
Factory default: OFF

---

## Status Query Commands (See the EtherCAT Communication Protocol Manual #20003335)

Query replies are examples that might be different from actual transducer reply.

### Device Type - DT

Specifies transducer device type name:

Query: @253DT?;FF  
Query reply: @253ACKDUALMAG;FF

### Firmware Version - FV

Specifies transducer firmware version:

Query: @253FV?;FF  
Query reply: @253ACK1.12;FF

### Hardware Version - HV

Specifies transducer hardware version:

Query: @253HV?;FF  
Query reply: @253ACKA;FF

### Manufacturer - MF

Specifies transducer manufacturer:

Query: @253MF?;FF  
Query reply: @253ACKMKS;FF

### Model - MD

Specifies transducer model number:

Query: @253MD?;FF  
Query reply: @253ACK972B;FF

### Part Number - PN

Specifies transducer part number:

Query: @253PN?;FF  
Query reply: @253ACK972B-11030;FF

### Serial Number - SN

Specifies transducer serial number:

Query: @253SN?;FF  
Query reply: @253ACK0925123456;FF

### Time ON - TIM

The TIM command returns the number of hours the transducer has been on:

Query: @253TIM?;FF  
Query reply: @253ACK123;FF

### Time ON 2 (Cold Cathode sensor) – TIM2

The TIM2 command returns the number of hours the cold cathode sensor has been on:

Query: @253TIM2?;FF  
Query reply: @253ACK123;FF

### Time ON 3 (Cold Cathode pressure dose) – TIM3 (not available in EtherCAT units)

The TIM3 command returns the cold cathode pressure dose:

Query: @253TIM3?;FF  
Query reply: @253ACK1.00E-2;FF

### Temperature - TEM (not available on EtherCAT units) (not available in EtherCAT units)

The TEM command returns the MicroPirani on chip sensor temperature °C typical within ±3 °C.

Query: @253TEM?;FF  
Query reply: @253ACK2.50E+1;FF

### Transducer Status – T (See the EtherCAT Communications Protocol manual #20003335)

The T command returns the Transducer sensor status as O for OK, M for MicroPirani failure, C for Cold Cathode failure, R pressure dose setpoint exceeded or G for Cold Cathode ON.

Query: @253T?;FF  
Query reply: @253ACKO;FF

## Analog output

The 972B transducer provides a voltage output as function of pressure.  
The standard output is 0.5 VDC/decade but can also be configured to emulate other analog outputs.

### Analog output calibration = 0 (MKS standard 0.5 VDC/decade)

$$P_{\text{Torr}} = 10^{(2 \times V_{\text{out}} - 11)}$$

$$V_{\text{out}} = \frac{\log_{10}(P_{\text{Torr}}) + 11}{2}$$


$$P_{\text{mbar}} = 10^{(2 \times V_{\text{out}} - 11)}$$

$$V_{\text{out}} = \frac{\log_{10}(P_{\text{mbar}}) + 11}{2}$$

$$P_{\text{Pascal}} = 10^{(2 \times V_{\text{out}} - 9)}$$

$$V_{\text{out}} = \frac{\text{Log}_{10}(P_{\text{Pascal}}) + 9}{2}$$

The standard MKS analog output always provides 0.5 VDC/decade. If the transducer pressure unit is changed from Torr to Pascal or mbar the analog output scaling will change as well, so it represents 0.5 VDC/decade Torr or 0.5 VDC/decade mbar or Pascal.



| Torr/mbar | Vout   | Torr/mbar | Vout   | Torr/mbar | Vout   | Torr/mbar | Vout   |
|-----------|--------|-----------|--------|-----------|--------|-----------|--------|
| 1.0E-8    | 1.5000 | 1.0E-5    | 3.0000 | 1.0E-2    | 4.5000 | 10        | 6.0000 |
| 2.0E-8    | 1.6505 | 2.0E-5    | 3.1505 | 2.0E-2    | 4.6505 | 20        | 6.1505 |
| 4.0E-8    | 1.8010 | 4.0E-5    | 3.3010 | 4.0E-2    | 4.8010 | 40        | 6.3010 |
| 6.0E-8    | 1.8891 | 6.0E-5    | 3.3891 | 6.0E-2    | 4.8891 | 60        | 6.3891 |
| 8.0E-8    | 1.9515 | 8.0E-5    | 3.4515 | 8.0E-2    | 4.9515 | 80        | 6.4515 |
| 1.0E-7    | 2.0000 | 1.0E-4    | 3.5000 | 1.0E-1    | 5.0000 | 100       | 6.5000 |
| 2.0E-7    | 2.1505 | 2.0E-4    | 3.6505 | 2.0E-1    | 5.1505 | 200       | 6.6505 |
| 4.0E-7    | 2.3010 | 4.0E-4    | 3.8010 | 4.0E-1    | 5.3010 | 400       | 6.8010 |
| 6.0E-7    | 2.3891 | 6.0E-4    | 3.8891 | 6.0E-1    | 5.3891 | 600       | 6.8891 |
| 8.0E-7    | 2.4515 | 8.0E-4    | 3.9515 | 8.0E-1    | 5.4515 | 760       | 6.9404 |
| 1.0E-6    | 2.5000 | 1.0E-3    | 4.0000 | 1.0       | 5.5000 | 800       | 6.9515 |
| 2.0E-6    | 2.6505 | 2.0E-3    | 4.1505 | 2.0       | 5.6505 |           |        |
| 4.0E-6    | 2.8010 | 4.0E-3    | 4.3010 | 4.0       | 5.8010 |           |        |
| 6.0E-6    | 2.8891 | 6.0E-3    | 4.3891 | 6.0       | 5.8891 |           |        |
| 8.0E-6    | 2.9515 | 8.0E-3    | 4.4515 | 8.0       | 5.9515 |           |        |

---

### Analog output setup (See the EtherCAT Communications Protocol manual #20003335)

The 972B can emulate analog voltage outputs from other vacuum transducers. The 972B analog output can be assigned to the MicroPirani sensor measurement (PR1), Cold Cathode sensor measurement (PR2, PR5) and the combined Cold cathode / MicroPirani reading (PR3). This is set by the first digit. The second and third digit represents the analog output calibration. The primary analog output provides 16 bit resolution.



**Due to curve form and limits, some of the alternative analog outputs will cause loss of measuring range and accuracy. For best performance use the standard MKS analog output. Change of analog output setup does not interfere on digital reading.**

Change of analog output setup:

|                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Command:         | @253AO1!15;FF                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Command values:  | 10 to 319 (xy)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| First digit (x)  | <b>1 = PR1 (MicroPirani pressure value assignment)</b><br>2 = PR2 (Cold Cathode pressure value assignment)<br>3 = PR3 (Combined pressure value assignment)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Second digit (y) | 0 = MKS Standard (0.5 VDC/decade)<br>1 = Edwards APG-L (1.99 -10 VDC)<br>2 = Edwards APG100<br>3 = Edwards WRG<br>4 = Inficon PSG500 /Oerlikon/Leybold TTR91<br><b>5 = Inficon MPG400 / Pfeiffer PKR251</b><br>6 = Inficon BPG400 / MKS 999 Quattro<br>7 = MKS 275<br>8 = MKS Moducell 325<br>9 = MKS Moducell 325 (x3)<br>10 = MKS Baratron 0.1 Torr (0-10 VDC)<br>11 = MKS Baratron 1 Torr (0-10 VDC) / Hasting 2002OBE, Channel 2<br>12 = MKS Baratron 10 Torr (0-10 VDC)<br>13 = MKS Baratron 100 Torr (0-10 VDC)<br>14 = MKS Baratron 1000 Torr (0-10 VDC) / Hasting 2002OBE, Channel 1<br>15 = Piezo differential output<br>16 = Edwards AIM-S /-SL<br>17 = Edwards AIM-X / XL<br>18 = Pfeiffer IKR251<br>19 = Pfeiffer TPR 265<br>20 = OBE Channel 2<br>21 = Edwards DV6M<br>22 = Edwards APG-M<br>23 = MKS 275 (0-9VDC)<br>24 = MT 241.1<br>25 = MKS 275 (0-5.6VDC)<br>26 = Edwards APG100-LC<br>27 = Edwards APG100M<br>28 = MKS 907<br>29 = K6080-06<br>30 = Inficon PEG100<br>31 = Varian Eyesys<br>32 = Alcatel TA111<br>33 = MKS 685 |
| Command reply:   | @253ACK15;FF                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Query:           | @253AO1?;FF                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Query reply:     | @253ACK15;FF                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Factory default: | 30                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

---

**Dual analog output (Optional)** *(not available on EtherCAT units)*

The 972B is available with dual analog output which can be used to provide an alternative output for amplification of range or to emulate another transducer type while still using the MKS standard output.

This feature is a hardware option and must be specially ordered. Refer to part number specifications page 5.

The secondary analog output provides 12 bit resolution.


Command: @253AO2!15;FF  
Command values: 10 to 319 (xy)  
First digit (x) *Use same parameters as primary analog output*  
Second digit (y) *Use same parameters as primary analog output*

Command reply: @253ACK15;FF  
Query: @253AO2?;FF  
Query reply: @253ACK15;FF  
Factory default: 30

### Analog output calibration = 1 (Edwards APG-L emulation)

The APG-L emulation provides a strongly non-linear output with very poor resolution in the low range and virtually no signal from 100 Torr to atmosphere.

| Torr    | mbar    | Pascal  | Vout  |
|---------|---------|---------|-------|
| 1.90E-5 | 2.53E-5 | 2.53E-3 | 1.99  |
| 3.00E-5 | 4.00E-5 | 4.00E-3 | 2.00  |
| 1.00E-4 | 1.33E-4 | 1.33E-2 | 2.04  |
| 5.00E-4 | 6.66E-4 | 6.66E-2 | 2.27  |
| 1.00E-3 | 1.33E-3 | 1.33E-1 | 2.50  |
| 2.00E-3 | 2.66E-3 | 2.66E-1 | 2.82  |
| 5.00E-3 | 6.66E-3 | 6.66E-1 | 3.34  |
| 7.00E-3 | 9.32E-3 | 9.32E-1 | 3.53  |
| 1.00E-2 | 1.33E-2 | 1.33    | 3.74  |
| 2.00E-2 | 2.66E-2 | 26.6    | 4.18  |
| 1.00E-1 | 1.33E-1 | 13.3    | 5.42  |
| 2.00E-1 | 2.66E-1 | 26.6    | 5.96  |
| 5.00E-1 | 6.66E-1 | 66.6    | 6.83  |
| 7.00E-1 | 9.32E-1 | 93.2    | 7.19  |
| 1.00    | 1.33    | 133     | 7.57  |
| 1.20    | 1.60    | 160     | 7.77  |
| 2.00    | 2.66    | 2.66    | 8.28  |
| 5.00    | 6.66    | 666     | 9.08  |
| 10.0    | 13.3    | 1.330   | 9.46  |
| 25.0    | 33.3    | 3.330   | 9.72  |
| 50.0    | 66.6    | 6.660   | 9.81  |
| 75.0    | 99.9    | 9.990   | 9.84  |
| 200     | 266     | 26.600  | 9.96  |
| 500     | 666     | 66.600  | 9.98  |
| 760     | 1013    | 101.300 | 10.00 |



### Analog output calibration = 2 (Edwards APG-100 emulation)

The APG-L emulation provides a log linear output of 1 VDC/mbar.

$$P_{Torr} = 10^{(V_{out} - 6.125)}$$

$$P_{mbar} = 10^{(V_{out} - 6)}$$


$$P_{Pascal} = 10^{(V_{out} - 4)}$$

$$V_{out} = \log_{10}(P_{Torr}) + 6.125$$

$$V_{out} = \log_{10}(P_{mbar}) + 6$$

$$V_{out} = \log_{10}(P_{Pascal}) + 4$$

| Torr    | mbar    | Pascal  | Vout |
|---------|---------|---------|------|
| 7.50E-5 | 1.00E-4 | 1.00E-2 | 2.00 |
| 7.50E-4 | 1.00E-3 | 1.00E-1 | 3.00 |
| 7.50E-3 | 1.00E-2 | 1.00    | 4.00 |
| 7.50E-2 | 1.00E-1 | 10.0    | 5.00 |
| 7.50E-1 | 1.00    | 100     | 6.00 |
| 7.50    | 10.0    | 1.000   | 7.00 |
| 75.0    | 100     | 10.000  | 8.00 |
| 750     | 1.000   | 100.000 | 9.00 |



### Analog output calibration = 3 (Edwards WRG emulation)

The WRG emulation covers a wider measuring range than supported by the 972B range.

$$P_{Torr} = 10^{(1.5 \times V_{out} - 12.125)}$$

$$P_{mbar} = 10^{(1.5 \times V_{out} - 12)}$$


$$P_{Pascal} = 10^{(1.5 \times V_{out} - 10)}$$

$$V_{out} = (\log_{10}(P_{Torr}) + 12.125) / 1.5$$

$$V_{out} = (\log_{10}(P_{mbar}) + 12) / 1.5$$

$$V_{out} = (\log_{10}(P_{Pascal}) + 10) / 1.5$$

| Torr    | mbar    | Pascal  | Vout  |
|---------|---------|---------|-------|
| 1.00E-8 | 1.33E-8 | 1.33E-6 | 2.75  |
| 2.37E-8 | 3.16E-8 | 3.16E-6 | 3.00  |
| 7.50E-7 | 1.00E-6 | 1.00E-4 | 4.00  |
| 2.37E-5 | 3.16E-5 | 3.16E-2 | 5.00  |
| 7.50E-4 | 1.00E-3 | 1.00E-1 | 6.00  |
| 2.37E-2 | 3.16E-2 | 3.16    | 7.00  |
| 7.50E-1 | 1.00    | 100     | 8.00  |
| 2.37    | 31.6    | 3.160   | 9.00  |
| 750.0   | 1.000   | 100.000 | 10.00 |



### Analog output calibration = 4 (Inficon PSG500 / Oerlikon TTR91 emulation)

The TTR91 emulation provides a log linear output. The output does not provide a pressure dependent signal at pressures below 2.00E-4 Torr.

$$P_{Torr} = 10^{((V_{out} - 6.304)/1.286)}$$

$$P_{mbar} = 10^{((V_{out} - 6.143)/1.286)}$$


$$P_{Pascal} = 10^{((V_{out} - 3.572)/1.286)}$$

$$V_{out} = \log_{10}(P_{Torr}) \times 1.286 + 6.304$$

$$V_{out} = \log_{10}(P_{mbar}) \times 1.286 + 6.143$$

$$V_{out} = \log_{10}(P_{Pascal}) \times 1.286 + 3.572$$

| Torr    | mbar    | Pascal  | Vout     |
|---------|---------|---------|----------|
| 1.00E-5 | 1.33E-5 | 1.33E-3 | 1.547    |
| 2.00E-4 | 2.67E-4 | 2.67E-2 | 1.547    |
| 5.00E-4 | 6.67E-4 | 6.67E-2 | 2.058    |
| 1.00E-3 | 1.33E-3 | 1.33E-1 | 2.446    |
| 1.00E-2 | 1.33E-2 | 1.33E+0 | 3.732    |
| 1.00E-1 | 1.33E-1 | 1.33E+1 | 5.018    |
| 1.00E+0 | 1.33E+0 | 1.33E+2 | 6.304    |
| 1.00E+1 | 1.33E+1 | 1.33E+3 | 7.59     |
| 1.00E+2 | 1.33E+2 | 1.33E+4 | 8.876    |
| 7.60E+2 | 1.01E+3 | 1.01E+5 | 10.00873 |



### Analog output calibration = 5 (Inficon MPG400 / Pfeiffer PKR251 emulation)

$$P_{\text{Torr}} = 10^{((V_{\text{out}} - 6.875)/0.6)}$$

$$P_{\text{mbar}} = 10^{((V_{\text{out}} - 6.8)/0.6)}$$


$$P_{\text{Pascal}} = 10^{((V_{\text{out}} - 5.6)/0.6)}$$

$$V_{\text{out}} = \log_{10}(P_{\text{Torr}}) \times 0.6 + 6.875$$

$$V_{\text{out}} = \log_{10}(P_{\text{mbar}}) \times 0.6 + 6.8$$

$$V_{\text{out}} = \log_{10}(P_{\text{Pascal}}) \times 0.6 + 5.6$$

| Torr    | mbar    | Pascal  | Vout  |
|---------|---------|---------|-------|
| 1.00E-8 | 1.33E-8 | 1.33E-6 | 2.075 |
| 1.00E-7 | 1.33E-7 | 1.33E-5 | 2.675 |
| 1.00E-6 | 1.33E-6 | 1.33E-4 | 3.275 |
| 1.00E-5 | 1.33E-5 | 1.33E-3 | 3.875 |
| 1.00E-4 | 1.33E-4 | 1.33E-2 | 4.475 |
| 1.00E-3 | 1.33E-3 | 1.33E-1 | 5.075 |
| 1.00E-2 | 1.33E-2 | 1.33E+0 | 5.675 |
| 1.00E-1 | 1.33E-1 | 1.33E+1 | 6.275 |
| 1.00E+0 | 1.33E+0 | 1.33E+2 | 6.875 |
| 1.00E+1 | 1.33E+1 | 1.33E+3 | 7.475 |
| 1.00E+2 | 1.33E+2 | 1.33E+4 | 8.075 |
| 7.60E+2 | 1.01E+3 | 1.01E+5 | 8.603 |



### Analog output calibration = 6 (Inficon BPG400 emulation)

$$P_{\text{Torr}} = 10^{((V_{\text{out}} - 7.75)/0.75)} - 0.125$$

$$P_{\text{mbar}} = 10^{(V_{\text{out}}/0.75)}$$


$$P_{\text{Pascal}} = 10^{(V_{\text{out}}/0.75)} + 2$$

$$V_{\text{out}} = \log_{10}(P_{\text{Torr}} + 0.125) \times 0.75 + 7.75$$

$$V_{\text{out}} = \log_{10}(P_{\text{mbar}}) \times 0.75$$

$$V_{\text{out}} = \log_{10}(P_{\text{Pascal}} - 2) \times 0.75$$


| Torr    | mbar    | Pascal  | Vout   |
|---------|---------|---------|--------|
| 1.00E-8 | 1.33E-8 | 1.33E-6 | 1.843  |
| 1.00E-7 | 1.33E-7 | 1.33E-5 | 2.593  |
| 1.00E-6 | 1.33E-6 | 1.33E-4 | 3.343  |
| 1.00E-5 | 1.33E-5 | 1.33E-3 | 4.093  |
| 1.00E-4 | 1.33E-4 | 1.33E-2 | 4.843  |
| 5.00E-4 | 6.67E-4 | 6.67E-2 | 5.367  |
| 1.00E-3 | 1.33E-3 | 1.33E-1 | 5.593  |
| 1.00E-2 | 1.33E-2 | 1.33E+0 | 6.343  |
| 1.00E-1 | 1.33E-1 | 1.33E+1 | 7.093  |
| 1.00E+0 | 1.33E+0 | 1.33E+2 | 7.843  |
| 1.00E+1 | 1.33E+1 | 1.33E+3 | 8.593  |
| 1.00E+2 | 1.33E+2 | 1.33E+4 | 9.343  |
| 7.60E+2 | 1.01E+3 | 1.01E+5 | 10.004 |



### Analog output calibration = 7 (MKS 275 emulation)

The MKS 275 emulation provides a strongly non-linear output with very poor resolution in the low range and close to atmospheric pressure.


| Torr    | mbar    | Pascal  | Vout  |
|---------|---------|---------|-------|
| 1.00E-5 | 1.33E-5 | 1.33E-3 | 0.372 |
| 1.00E-4 | 1.33E-4 | 1.33E-2 | 0.372 |
| 2.50E-4 | 3.33E-4 | 3.33E-2 | 0.376 |
| 5.00E-4 | 6.67E-4 | 6.67E-2 | 0.381 |
| 7.50E-4 | 1.00E-3 | 1.00E-1 | 0.385 |
| 1.00E-3 | 1.33E-3 | 1.33E-1 | 0.388 |
| 2.50E-3 | 3.33E-3 | 3.33E-1 | 0.406 |
| 5.00E-3 | 6.67E-3 | 6.67E-1 | 0.431 |
| 7.50E-3 | 1.00E-2 | 1.00E+0 | 0.452 |
| 1.00E-2 | 1.33E-2 | 1.33E+0 | 0.470 |
| 2.50E-2 | 3.33E-2 | 3.33E+0 | 0.563 |
| 5.00E-2 | 6.67E-2 | 6.67E+0 | 0.682 |
| 7.50E-2 | 1.00E-1 | 1.00E+1 | 0.780 |
| 1.00E-1 | 1.33E-1 | 1.33E+1 | 0.867 |
| 2.50E-1 | 3.33E-1 | 3.33E+1 | 1.255 |
| 5.00E-1 | 6.67E-1 | 6.67E+1 | 1.684 |
| 7.50E-1 | 1.00E+0 | 1.00E+2 | 1.990 |
| 1.00E+0 | 1.33E+0 | 1.33E+2 | 2.228 |
| 2.50E+0 | 3.33E+0 | 3.33E+2 | 3.053 |
| 5.00E+0 | 6.67E+0 | 6.67E+2 | 3.664 |
| 7.50E+0 | 1.00E+1 | 1.00E+3 | 3.986 |
| 1.00E+1 | 1.33E+1 | 1.33E+3 | 4.191 |
| 2.50E+1 | 3.33E+1 | 3.33E+3 | 4.706 |
| 5.00E+1 | 6.67E+1 | 6.67E+3 | 4.965 |
| 7.50E+1 | 1.00E+2 | 1.00E+4 | 5.075 |
| 1.00E+2 | 1.33E+2 | 1.33E+4 | 5.137 |
| 2.50E+2 | 3.33E+2 | 3.33E+4 | 5.274 |
| 5.00E+2 | 6.67E+2 | 6.67E+4 | 5.333 |
| 6.00E+2 | 8.00E+2 | 8.00E+4 | 5.345 |
| 7.00E+2 | 9.33E+2 | 9.33E+4 | 5.353 |
| 7.60E+2 | 1.01E+3 | 1.01E+5 | 5.357 |
| 8.00E+2 | 1.07E+3 | 1.07E+5 | 5.360 |



### Analog out calibration = 8 (MKS Moducell 325)

The Moducell emulation provides a strongly non-linear output.


| Torr    | mbar    | Pascal  | Vout   |
|---------|---------|---------|--------|
| 1.00E-5 | 1.33E-5 | 1.33E-3 | 0.2509 |
| 1.00E-4 | 1.33E-4 | 1.33E-2 | 0.2524 |
| 2.50E-4 | 3.33E-4 | 3.33E-2 | 0.2550 |
| 5.00E-4 | 6.67E-4 | 6.67E-2 | 0.2592 |
| 7.50E-4 | 1.00E-3 | 1.00E-1 | 0.2633 |
| 1.00E-3 | 1.33E-3 | 1.33E-1 | 0.2674 |
| 2.50E-3 | 3.33E-3 | 3.33E-1 | 0.2905 |
| 5.00E-3 | 6.67E-3 | 6.67E-1 | 0.3251 |
| 7.50E-3 | 1.00E-2 | 1.00E+0 | 0.3561 |
| 1.00E-2 | 1.33E-2 | 1.33E+0 | 0.3845 |
| 2.50E-2 | 3.33E-2 | 3.33E+0 | 0.5215 |
| 5.00E-2 | 6.67E-2 | 6.67E+0 | 0.6868 |
| 7.50E-2 | 1.00E-1 | 1.00E+1 | 0.8144 |
| 1.00E-1 | 1.33E-1 | 1.33E+1 | 0.9205 |
| 2.50E-1 | 3.33E-1 | 3.33E+1 | 1.3489 |
| 5.00E-1 | 6.67E-1 | 6.67E+1 | 1.7504 |
| 7.50E-1 | 1.00E+0 | 1.00E+2 | 1.9986 |
| 1.00E+0 | 1.33E+0 | 1.33E+2 | 2.1720 |
| 2.50E+0 | 3.33E+0 | 3.33E+2 | 2.6512 |
| 5.00E+0 | 6.67E+0 | 6.67E+2 | 2.9012 |
| 7.50E+0 | 1.00E+1 | 1.00E+3 | 3.0022 |
| 1.00E+1 | 1.33E+1 | 1.33E+3 | 3.0569 |
| 2.50E+1 | 3.33E+1 | 3.33E+3 | 3.1639 |
| 5.00E+1 | 6.67E+1 | 6.67E+3 | 3.2023 |
| 7.50E+1 | 1.00E+2 | 1.00E+4 | 3.2154 |
| 1.00E+2 | 1.33E+2 | 1.33E+4 | 3.2221 |
| 2.50E+2 | 3.33E+2 | 3.33E+4 | 3.2342 |
| 5.00E+2 | 6.67E+2 | 6.67E+4 | 3.2382 |
| 6.00E+2 | 8.00E+2 | 8.00E+4 | 3.2389 |
| 7.00E+2 | 9.33E+2 | 9.33E+4 | 3.2394 |
| 7.60E+2 | 1.01E+3 | 1.01E+5 | 3.2396 |
| 8.00E+2 | 1.07E+3 | 1.07E+5 | 3.2398 |



### Analog out calibration = 9 (MKS Moducell 325, amplified 3 times)

The Moducell x3 emulation is in curve form identical with the standard Moducell, however, to provide better signal resolution the signal is amplified by a factor three.


| Torr    | mbar    | Pascal  | Vout  |
|---------|---------|---------|-------|
| 1.00E-5 | 1.33E-5 | 1.33E-3 | 0.753 |
| 1.00E-4 | 1.33E-4 | 1.33E-2 | 0.757 |
| 2.50E-4 | 3.33E-4 | 3.33E-2 | 0.765 |
| 5.00E-4 | 6.67E-4 | 6.67E-2 | 0.778 |
| 7.50E-4 | 1.00E-3 | 1.00E-1 | 0.790 |
| 1.00E-3 | 1.33E-3 | 1.33E-1 | 0.802 |
| 2.50E-3 | 3.33E-3 | 3.33E-1 | 0.871 |
| 5.00E-3 | 6.67E-3 | 6.67E-1 | 0.975 |
| 7.50E-3 | 1.00E-2 | 1.00E+0 | 1.068 |
| 1.00E-2 | 1.33E-2 | 1.33E+0 | 1.154 |
| 2.50E-2 | 3.33E-2 | 3.33E+0 | 1.565 |
| 5.00E-2 | 6.67E-2 | 6.67E+0 | 2.060 |
| 7.50E-2 | 1.00E-1 | 1.00E+1 | 2.443 |
| 1.00E-1 | 1.33E-1 | 1.33E+1 | 2.762 |
| 2.50E-1 | 3.33E-1 | 3.33E+1 | 4.047 |
| 5.00E-1 | 6.67E-1 | 6.67E+1 | 5.251 |
| 7.50E-1 | 1.00E+0 | 1.00E+2 | 5.996 |
| 1.00E+0 | 1.33E+0 | 1.33E+2 | 6.516 |
| 2.50E+0 | 3.33E+0 | 3.33E+2 | 7.954 |
| 5.00E+0 | 6.67E+0 | 6.67E+2 | 8.704 |
| 7.50E+0 | 1.00E+1 | 1.00E+3 | 9.007 |
| 1.00E+1 | 1.33E+1 | 1.33E+3 | 9.171 |
| 2.50E+1 | 3.33E+1 | 3.33E+3 | 9.492 |
| 5.00E+1 | 6.67E+1 | 6.67E+3 | 9.607 |
| 7.50E+1 | 1.00E+2 | 1.00E+4 | 9.646 |
| 1.00E+2 | 1.33E+2 | 1.33E+4 | 9.666 |
| 2.50E+2 | 3.33E+2 | 3.33E+4 | 9.702 |
| 5.00E+2 | 6.67E+2 | 6.67E+4 | 9.715 |
| 6.00E+2 | 8.00E+2 | 8.00E+4 | 9.717 |
| 7.00E+2 | 9.33E+2 | 9.33E+4 | 9.718 |
| 7.60E+2 | 1.01E+3 | 1.01E+5 | 9.719 |
| 8.00E+2 | 1.07E+3 | 1.07E+5 | 9.719 |



### Analog out calibration = 10 (MKS Baratron 0.1 Torr)

The 0.1 Torr Baratron emulation provides a signal directly proportional with pressure with a full scale reading of 10 VDC at 0.1 Torr.


| Torr    | mbar    | Pascal  | Vout   |
|---------|---------|---------|--------|
| 1.00E-3 | 1.33E-3 | 1.33E-1 | 0.100  |
| 5.00E-3 | 6.66E-3 | 6.66E-1 | 0.500  |
| 1.00E-2 | 1.33E-2 | 1.33E0  | 1.000  |
| 5.00E-2 | 6.66E-2 | 6.66E0  | 5.000  |
| 1.00E-1 | 1.33E-1 | 1.33E+1 | 10.000 |



### Analog out calibration = 11 (MKS Baratron 1 Torr)

The 1 Torr Baratron emulation provides a signal directly proportional with pressure with a full scale reading of 10 VDC at 1 Torr.


| Torr    | mbar    | Pascal  | Vout   |
|---------|---------|---------|--------|
| 1.00E-2 | 1.33E-2 | 1.33E0  | 0.100  |
| 5.00E-2 | 6.66E-2 | 6.66E0  | 0.500  |
| 1.00E-1 | 1.33E-1 | 1.33E+1 | 1.000  |
| 5.00E-1 | 6.66E-1 | 6.66E+1 | 5.000  |
| 1.00E0  | 1.33E0  | 1.33E+2 | 10.000 |



### Analog out calibration = 12 (MKS Baratron 10 Torr)

The 10 Torr Baratron emulation provides a signal directly proportional with pressure with a full scale reading of 10 VDC at 10 Torr.


| Torr    | mbar    | Pascal  | Vout   |
|---------|---------|---------|--------|
| 1.00E-1 | 1.33E-1 | 1.33E+1 | 1.000  |
| 5.00E-1 | 6.66E-1 | 6.66E+1 | 5.000  |
| 1.00E0  | 1.33E0  | 1.33E+2 | 10.000 |
| 5.00E0  | 6.66E0  | 6.66E+2 | 5.000  |
| 1.00E+1 | 1.33E+1 | 1.33E+3 | 10.000 |



### Analog out calibration = 13 (MKS Baratron 100 Torr)

The 100 Torr Baratron emulation provides a signal directly proportional with pressure with a full scale reading of 10 VDC at 100 Torr.


| Torr  | mbar  | Pascal   | Vout  |
|-------|-------|----------|-------|
| 1.0   | 1.33  | 1.333E+2 | 0.100 |
| 5.0   | 6.66  | 6.66E+2  | 0.500 |
| 10.0  | 13.3  | 1.333E+3 | 0.100 |
| 50.0  | 66.66 | 6.66E+3  | 0.500 |
| 100.0 | 133.3 | 1.333E+4 | 1.000 |



### Analog out calibration = 14 (MKS Baratron 1000 Torr)

The 1000 Torr Baratron emulation provides a signal directly proportional with pressure with a full scale reading of 10 VDC at 1000 Torr.


| Torr  | mbar    | Pascal    | Vout   |
|-------|---------|-----------|--------|
| 10.0  | 13.3    | 1.333E+3  | 0.100  |
| 50.0  | 66.66   | 6.66E+3   | 0.500  |
| 100.0 | 133.3   | 1.333E+4  | 1.000  |
| 500.0 | 666.6   | 6.666E+4  | 5.000  |
| 1,000 | 1,333.2 | 1.3332E+5 | 10.000 |



### Analog out calibration = 16 (Edwards AIM-S /-SL)

The Edwards AIM-S / SL emulation provides a strongly non-linear output.


| Torr    | mbar    | Pascal  | Vout |
|---------|---------|---------|------|
| 1.00E-8 | 1.33E-8 | 1.33E-6 | 2.5  |
| 1.80E-8 | 2.40E-8 | 2.40E-6 | 2.5  |
| 4.40E-8 | 5.87E-8 | 5.87E-6 | 3    |
| 6.10E-8 | 8.13E-8 | 8.13E-6 | 3.2  |
| 8.30E-8 | 1.11E-7 | 1.11E-5 | 3.4  |
| 1.10E-7 | 1.47E-7 | 1.47E-5 | 3.6  |
| 2.20E-7 | 2.93E-7 | 2.93E-5 | 4    |
| 5.50E-7 | 7.33E-7 | 7.33E-5 | 4.6  |
| 7.40E-7 | 9.87E-7 | 9.87E-5 | 4.8  |
| 9.80E-7 | 1.31E-6 | 1.31E-4 | 5    |
| 1.30E-6 | 1.73E-6 | 1.73E-4 | 5.2  |
| 2.10E-6 | 2.80E-6 | 2.80E-4 | 5.6  |
| 3.40E-6 | 4.53E-6 | 4.53E-4 | 6    |
| 4.20E-6 | 5.60E-6 | 5.60E-4 | 6.2  |
| 5.20E-6 | 6.93E-6 | 6.93E-4 | 6.4  |
| 7.50E-6 | 1.00E-5 | 1.00E-3 | 6.8  |
| 9.00E-6 | 1.20E-5 | 1.20E-3 | 7    |
| 1.10E-5 | 1.47E-5 | 1.47E-3 | 7.2  |
| 2.20E-5 | 2.93E-5 | 2.93E-3 | 8    |
| 3.20E-5 | 4.27E-5 | 4.27E-3 | 8.4  |
| 4.30E-5 | 5.73E-5 | 5.73E-3 | 8.6  |
| 5.90E-5 | 7.87E-5 | 7.87E-3 | 8.8  |
| 9.00E-5 | 1.20E-4 | 1.20E-2 | 9    |
| 1.40E-4 | 1.87E-4 | 1.87E-2 | 9.2  |
| 2.5E-4  | 3.33E-4 | 3.33E-2 | 9.4  |
| 5.0E-4  | 6.67E-4 | 6.67E-2 | 9.6  |
| 1.3E-3  | 1.73E-3 | 1.73E-1 | 9.8  |
| 2.7E-3  | 3.60E-3 | 3.60E-1 | 9.9  |
| 7.5E-3  | 1.00E-2 | 1.00E+  | 10   |



### Analog out calibration = 17 (Edwards AIM-X /-XL)

The Edwards AIM-X / XL emulation provides a log linear output.

| Torr    | mbar    | Pascal  | Vout  |
|---------|---------|---------|-------|
| 1.00E-8 | 1.33E-8 | 1.33E-6 | 3.286 |
| 5.00E-8 | 6.67E-8 | 6.67E-6 | 4.084 |
| 1.00E-7 | 1.33E-7 | 1.33E-5 | 4.428 |
| 5.00E-7 | 6.67E-7 | 6.67E-5 | 5.227 |
| 1.00E-6 | 1.33E-6 | 1.33E-4 | 5.571 |
| 5.00E-6 | 6.67E-6 | 6.67E-4 | 6.370 |
| 1.00E-5 | 1.33E-5 | 1.33E-3 | 6.714 |
| 5.00E-5 | 6.67E-5 | 6.67E-3 | 7.513 |
| 1.00E-4 | 1.33E-4 | 1.33E-2 | 7.857 |
| 5.00E-4 | 6.67E-4 | 6.67E-2 | 8.656 |
| 1.00E-3 | 1.33E-3 | 1.33E-1 | 9.000 |
| 5.00E-3 | 6.67E-3 | 6.67E-1 | 9.799 |



### Analog out calibration = 18 (Pfeiffer IKR251)


The Pfeiffer IKR251 emulation provides a log linear output.

| Torr    | mbar    | Pascal  | Vout   |
|---------|---------|---------|--------|
| 5.00E-9 | 6.67E-9 | 6.67E-7 | 2.3240 |
| 1.00E-8 | 1.33E-8 | 1.33E-6 | 2.6250 |
| 5.00E-8 | 6.67E-8 | 6.67E-6 | 3.3240 |
| 1.00E-7 | 1.33E-7 | 1.33E-5 | 3.6250 |
| 5.00E-7 | 6.67E-7 | 6.67E-5 | 4.3240 |
| 1.00E-6 | 1.33E-6 | 1.33E-4 | 4.6250 |
| 5.00E-6 | 6.67E-6 | 6.67E-4 | 5.3240 |
| 1.00E-5 | 1.33E-5 | 1.33E-3 | 5.6250 |
| 5.00E-5 | 6.67E-5 | 6.67E-3 | 6.3240 |
| 1.00E-4 | 1.33E-4 | 1.33E-2 | 6.6250 |
| 5.00E-4 | 6.67E-4 | 6.67E-2 | 7.3240 |
| 1.00E-3 | 1.33E-3 | 1.33E-1 | 7.6250 |
| 5.00E-3 | 6.67E-3 | 6.67E-1 | 8.3240 |
| 9.00E-3 | 1.20E-2 | 1.20E+0 | 8.5000 |

$$P = 10^{V_{out} - c}$$

$$V_{out} = c + \log_{10}(P)$$


mbar 10.5  
 Torr 10.625  
 Pa 8.5



### Analog out calibration = 19 (Pfeiffer TPR265)

The Pfeiffer TPR265 emulation provides a log linear output.


| Torr    | mbar    | Pascal  | Vout  |
|---------|---------|---------|-------|
| 1.00E-4 | 1.33E-4 | 1.33E-2 | 2.199 |
| 4.00E-4 | 5.33E-4 | 5.33E-2 | 2.227 |
| 5.00E-4 | 6.67E-4 | 6.67E-2 | 2.324 |
| 1.00E-3 | 1.33E-3 | 1.33E-1 | 2.625 |
| 5.00E-3 | 6.67E-3 | 6.67E-1 | 3.324 |
| 1.00E-2 | 1.33E-2 | 1.33E+0 | 3.625 |
| 5.00E-2 | 6.67E-2 | 6.67E+0 | 4.324 |
| 1.00E-1 | 1.33E-1 | 1.33E+1 | 4.625 |
| 5.00E-1 | 6.67E-1 | 6.67E+1 | 5.324 |
| 1.00E+0 | 1.33E+0 | 1.33E+2 | 5.625 |
| 5.00E+0 | 6.67E+0 | 6.67E+2 | 6.324 |
| 1.00E+1 | 1.33E+1 | 1.33E+3 | 6.625 |
| 5.00E+1 | 6.67E+1 | 6.67E+3 | 7.324 |
| 1.00E+2 | 1.33E+2 | 1.33E+4 | 7.625 |
| 5.00E+2 | 6.67E+2 | 6.67E+4 | 8.324 |
| 9.00E+2 | 1.20E+3 | 1.20E+5 | 8.579 |
| 1.00E+3 | 1.33E+3 | 1.33E+5 | 8.625 |



### Analog out calibration = 20 (OBE Special)

The OBE special emulation provides a linear output from 1 to 1000 Torr.


| Torr | mbar    | Pascal  | Vout  |
|------|---------|---------|-------|
| 0.1  | 1.33E-1 | 1.33E+1 | 5     |
| 1    | 1.33E+0 | 1.33E+2 | 5     |
| 2    | 2.67E+0 | 2.67E+2 | 5.005 |
| 4    | 5.33E+0 | 5.33E+2 | 5.015 |
| 5    | 6.67E+0 | 6.67E+2 | 5.02  |
| 10   | 1.33E+1 | 1.33E+3 | 5.045 |
| 25   | 3.33E+1 | 3.33E+3 | 5.12  |
| 50   | 6.67E+1 | 6.67E+3 | 5.245 |
| 75   | 1.00E+2 | 1.00E+4 | 5.37  |
| 100  | 1.33E+2 | 1.33E+4 | 5.495 |
| 250  | 3.33E+2 | 3.33E+4 | 6.245 |
| 500  | 6.67E+2 | 6.67E+4 | 7.495 |
| 750  | 1.00E+3 | 1.00E+5 | 8.745 |
| 1000 | 1.33E+3 | 1.33E+5 | 9.995 |



### Analog out calibration = 21 (Edwards DV6M)

The Edwards DV6M emulation provides a strongly non-linear output with up to 10 Torr.


| Torr   | mbar    | Pascal  | Vout |
|--------|---------|---------|------|
| 0.0001 | 1.33E-4 | 1.33E-2 | 2    |
| 0.0005 | 6.67E-4 | 6.67E-2 | 2.19 |
| 0.001  | 1.33E-3 | 1.33E-1 | 2.25 |
| 0.002  | 2.67E-3 | 2.67E-1 | 2.38 |
| 0.004  | 5.33E-3 | 5.33E-1 | 2.62 |
| 0.006  | 8.00E-3 | 8.00E-1 | 2.84 |
| 0.008  | 1.07E-2 | 1.07E+0 | 3.06 |
| 0.01   | 1.33E-2 | 1.33E+0 | 3.27 |
| 0.02   | 2.67E-2 | 2.67E+0 | 4.16 |
| 0.04   | 5.33E-2 | 5.33E+0 | 5.56 |
| 0.05   | 6.67E-2 | 6.67E+0 | 6.01 |
| 0.06   | 8.00E-2 | 8.00E+0 | 6.46 |
| 0.08   | 1.07E-1 | 1.07E+1 | 7.04 |
| 0.1    | 1.33E-1 | 1.33E+1 | 7.42 |
| 0.2    | 2.67E-1 | 2.67E+1 | 8.59 |
| 0.4    | 5.33E-1 | 5.33E+1 | 9.4  |
| 0.5    | 6.67E-1 | 6.67E+1 | 9.5  |
| 0.6    | 8.00E-1 | 8.00E+1 | 9.6  |
| 0.8    | 1.07E+0 | 1.07E+2 | 9.71 |
| 1      | 1.33E+0 | 1.33E+2 | 9.76 |
| 2      | 2.67E+0 | 2.67E+2 | 9.89 |
| 4      | 5.33E+0 | 5.33E+2 | 9.96 |
| 5      | 6.67E+0 | 6.67E+2 | 9.97 |
| 10     | 1.33E+1 | 1.33E+3 | 10   |



### Analog out calibration = 22 (Edwards APG-M)

The Edwards APG-M emulation provides a strongly non-linear output.


| Torr    | mbar    | Pascal  | Vout |
|---------|---------|---------|------|
| 1.00E-4 | 1.33E-4 | 1.33E-1 | 2.0  |
| 1.02E-3 | 1.36E-3 | 1.36E-1 | 2.2  |
| 7.65E-3 | 1.02E-2 | 1.02E+0 | 3    |
| 4.12E-2 | 5.49E-2 | 5.49E+0 | 4    |
| 1.32E-1 | 1.76E-1 | 1.76E+1 | 5    |
| 5.12E-1 | 6.83E-1 | 6.83E+1 | 6    |
| 1.4     | 1.87E+0 | 1.87E+2 | 7    |
| 3.29    | 4.39E+0 | 4.39E+2 | 8    |
| 9.53    | 1.27E+1 | 1.27E+3 | 9    |
| 16.8    | 2.24E+1 | 2.24E+3 | 9.4  |
| 26.5    | 3.53E+1 | 3.53E+3 | 9.6  |
| 49.9    | 6.65E+1 | 6.65E+3 | 9.8  |
| 106     | 1.41E+2 | 1.41E+4 | 9.9  |
| 462     | 6.16E+2 | 6.16E+4 | 9.95 |
| 760     | 1.01E+3 | 1.01E+5 | 10   |



### Analog Output calibration = 23 (MKS 275 Emulation 9 VDC FS)

The MKS 275 with 9VDC full scale emulation provides a strongly non-linear output with very poor resolution in the low range and close to atmospheric pressure.


| Torr    | mbar    | Pascal  | Vout  |
|---------|---------|---------|-------|
| 1.00E-3 | 1.34E-3 | 1.34E-1 | 0.015 |
| 1.32E-3 | 1.76E-3 | 1.76E-1 | 0.020 |
| 3.38E-3 | 4.51E-3 | 4.51E-1 | 0.050 |
| 4.81E-3 | 6.41E-3 | 6.41E-1 | 0.070 |
| 6.28E-3 | 8.37E-3 | 8.37E-1 | 0.090 |
| 7.03E-3 | 9.37E-3 | 9.37E-1 | 0.100 |
| 1.52E-2 | 2.02E-2 | 2.02E+0 | 0.200 |
| 2.45E-2 | 3.26E-2 | 3.26E+0 | 0.300 |
| 3.50E-2 | 4.66E-2 | 4.66E+0 | 0.400 |
| 4.67E-2 | 6.23E-2 | 6.23E+0 | 0.500 |
| 5.98E-2 | 7.97E-2 | 7.97E+0 | 0.600 |
| 7.42E-2 | 9.90E-2 | 9.90E+0 | 0.700 |
| 9.01E-2 | 1.20E-1 | 1.20E+1 | 0.800 |
| 1.07E-1 | 1.43E-1 | 1.43E+1 | 0.900 |
| 1.26E-1 | 1.68E-1 | 1.68E+1 | 1.000 |
| 1.69E-1 | 2.25E-1 | 2.25E+1 | 1.200 |
| 2.18E-1 | 2.90E-1 | 2.90E+1 | 1.400 |
| 2.74E-1 | 3.65E-1 | 3.65E+1 | 1.600 |
| 3.53E-1 | 4.71E-1 | 4.71E+1 | 1.846 |
| 0.4092  | 5.46E-1 | 5.46E+1 | 2.000 |
| 0.4879  | 6.51E-1 | 6.51E+1 | 2.200 |
| 0.5755  | 7.67E-1 | 7.67E+1 | 2.400 |
| 0.6734  | 8.98E-1 | 8.98E+1 | 2.600 |
| 0.7836  | 1.04E+0 | 1.04E+2 | 2.800 |
| 0.9076  | 1.21E+0 | 1.21E+2 | 3.000 |
| 1.02    | 1.36E+0 | 1.36E+2 | 3.164 |
| 1.28    | 1.71E+0 | 1.71E+2 | 3.500 |
| 1.77    | 2.37E+0 | 2.37E+2 | 4.000 |
| 2.24    | 2.98E+0 | 2.98E+2 | 4.390 |
| 3.26    | 4.34E+0 | 4.34E+2 | 5.000 |
| 4.57    | 6.09E+0 | 6.09E+2 | 5.500 |
| 6.65    | 8.86E+0 | 8.86E+2 | 6.000 |
| 10.1    | 1.34E+1 | 1.34E+3 | 6.548 |
| 12.9    | 1.71E+1 | 1.71E+3 | 6.800 |
| 16.1    | 2.15E+1 | 2.15E+3 | 7.000 |
| 29.4    | 3.92E+1 | 3.92E+3 | 7.383 |
| 56.6    | 7.55E+1 | 7.55E+3 | 7.647 |
| 64.1    | 8.55E+1 | 8.55E+3 | 7.700 |
| 114.1   | 1.52E+2 | 1.52E+4 | 7.800 |
| 200.7   | 2.68E+2 | 2.68E+4 | 7.910 |
| 257.0   | 3.43E+2 | 3.43E+4 | 8.000 |
| 314.3   | 4.19E+2 | 4.19E+4 | 8.100 |
| 368.5   | 4.91E+2 | 4.91E+4 | 8.200 |
| 478.0   | 6.37E+2 | 6.37E+4 | 8.400 |
| 606.0   | 8.08E+2 | 8.08E+4 | 8.600 |
| 773.1   | 1.03E+3 | 1.03E+5 | 8.800 |



### Analog Output calibration = 24 (Thyracont MT241.1-5)

The MT241 emulation provides a strongly non-linear output with limited resolution in the low range and close to atmosphere.


| Torr    | mbar     | Pascal   | V <sub>out</sub> |
|---------|----------|----------|------------------|
| 7.50E-4 | 1.00E-03 | 1.00E-01 | 0.41             |
| 3.00E-3 | 4.00E-03 | 4.00E-01 | 0.48             |
| 3.75E-3 | 5.00E-03 | 5.00E-01 | 0.5              |
| 6.00E-3 | 8.00E-03 | 8.00E-01 | 0.55             |
| 7.50E-3 | 1.00E-02 | 1.00E+00 | 0.61             |
| 1.50E-2 | 2.00E-02 | 2.00E+00 | 0.79             |
| 3.00E-2 | 4.00E-02 | 4.00E+00 | 1.1              |
| 4.50E-2 | 6.00E-02 | 6.00E+00 | 1.37             |
| 6.00E-2 | 8.00E-02 | 8.00E+00 | 1.6              |
| 7.50E-2 | 1.00E-01 | 1.00E+01 | 1.83             |
| 1.50E-1 | 2.00E-01 | 2.00E+01 | 2.64             |
| 2.25E-1 | 3.00E-01 | 3.00E+01 | 3.2              |
| 3.00E-1 | 4.00E-01 | 4.00E+01 | 3.71             |
| 3.75E-1 | 5.00E-01 | 5.00E+01 | 4                |
| 4.50E-1 | 6.00E-01 | 6.00E+01 | 4.45             |
| 6.00E-1 | 8.00E-01 | 8.00E+01 | 5                |
| 7.50E-1 | 1.00E+00 | 1.00E+02 | 5.44             |
| 3       | 4.00E+00 | 4.00E+02 | 7.96             |
| 5       | 6.00E+00 | 6.00E+02 | 8.5              |
| 8       | 1.00E+01 | 1.00E+03 | 9.01             |
| 15      | 2.00E+01 | 2.00E+03 | 9.45             |
| 30      | 4.00E+01 | 4.00E+03 | 9.7              |
| 45      | 6.00E+01 | 6.00E+03 | 9.78             |
| 75      | 1.00E+02 | 1.00E+04 | 9.85             |
| 150     | 2.00E+02 | 2.00E+04 | 9.92             |
| 300     | 4.00E+02 | 4.00E+04 | 9.95             |
| 450     | 6.00E+02 | 6.00E+04 | 9.96             |
| 600     | 8.00E+02 | 8.00E+04 | 9.98             |
| 750.06  | 1.00E+03 | 1.00E+05 | 9.99             |



### Analog Output calibration = 25 (MKS 275 Emulation 5.6 VDC FS)

The MKS 275 emulation with 5.6VDC full scale provides a strongly non-linear output with very poor resolution in the low range and close to atmospheric pressure.


| Torr     | mbar     | Pascal   | V <sub>out</sub> |
|----------|----------|----------|------------------|
| 1.00E-04 | 1.33E-04 | 1.33E-02 | 0.375            |
| 2.00E-04 | 2.67E-04 | 2.67E-02 | 0.377            |
| 5.00E-04 | 6.67E-04 | 6.67E-02 | 0.379            |
| 1.00E-03 | 1.33E-03 | 1.33E-01 | 0.384            |
| 2.00E-03 | 2.67E-03 | 2.67E-01 | 0.392            |
| 5.00E-03 | 6.67E-03 | 6.67E-01 | 0.417            |
| 1.00E-02 | 1.33E-02 | 1.33E+00 | 0.455            |
| 2.00E-02 | 2.67E-02 | 2.67E+00 | 0.523            |
| 5.00E-02 | 6.67E-02 | 6.67E+00 | 0.682            |
| 1.00E-01 | 1.33E-01 | 1.33E+01 | 0.878            |
| 2.00E-01 | 2.67E-01 | 2.67E+01 | 1.155            |
| 5.00E-01 | 6.67E-01 | 6.67E+01 | 1.683            |
| 1.00E+00 | 1.33E+00 | 1.33E+02 | 2.217            |
| 2.00E+00 | 2.67E+00 | 2.67E+02 | 2.842            |
| 5.00E+00 | 6.67E+00 | 6.67E+02 | 3.675            |
| 1.00E+01 | 1.33E+01 | 1.33E+03 | 4.206            |
| 2.00E+01 | 2.67E+01 | 2.67E+03 | 4.577            |
| 5.00E+01 | 6.67E+01 | 6.67E+03 | 4.846            |
| 1.00E+02 | 1.33E+02 | 1.33E+04 | 4.945            |
| 2.00E+02 | 2.67E+02 | 2.67E+04 | 5.019            |
| 3.00E+02 | 4.00E+02 | 4.00E+04 | 5.111            |
| 4.00E+02 | 5.33E+02 | 5.33E+04 | 5.224            |
| 5.00E+02 | 6.67E+02 | 6.67E+04 | 5.329            |
| 6.00E+02 | 8.00E+02 | 8.00E+04 | 5.419            |
| 7.00E+02 | 9.33E+02 | 9.33E+04 | 5.495            |
| 7.60E+02 | 1.01E+03 | 1.01E+05 | 5.534            |
| 8.00E+02 | 1.07E+03 | 1.07E+05 | 5.558            |
| 9.00E+02 | 1.20E+03 | 1.20E+05 | 5.614            |



## Analog Output calibration = 26 (Edwards APG100-LC)

The APG100-L emulation provides a strongly non linear output with limited resolution in the low range and close to atmosphere.


| Torr     | mbar     | Pascal   | Vout |
|----------|----------|----------|------|
| 7.50E-06 | 1.00E-05 | 1.00E-03 | 2    |
| 1.70E-04 | 2.27E-04 | 2.27E-02 | 2.1  |
| 3.75E-04 | 5.00E-04 | 5.00E-02 | 2.2  |
| 8.10E-04 | 1.08E-03 | 1.08E-01 | 2.4  |
| 1.26E-03 | 1.68E-03 | 1.68E-01 | 2.6  |
| 1.95E-03 | 2.60E-03 | 2.60E-01 | 2.8  |
| 2.88E-03 | 3.84E-03 | 3.84E-01 | 3    |
| 3.86E-03 | 5.15E-03 | 5.15E-01 | 3.2  |
| 5.15E-03 | 6.87E-03 | 6.87E-01 | 3.4  |
| 7.88E-03 | 1.05E-02 | 1.05E+00 | 3.6  |
| 1.17E-02 | 1.56E-02 | 1.56E+00 | 3.8  |
| 1.58E-02 | 2.10E-02 | 2.10E+00 | 4    |
| 2.08E-02 | 2.77E-02 | 2.77E+00 | 4.2  |
| 2.59E-02 | 3.45E-02 | 3.45E+00 | 4.4  |
| 3.12E-02 | 4.16E-02 | 4.16E+00 | 4.6  |
| 3.78E-02 | 5.04E-02 | 5.04E+00 | 4.8  |
| 4.44E-02 | 5.92E-02 | 5.92E+00 | 5    |
| 6.56E-02 | 8.74E-02 | 8.74E+00 | 5.2  |
| 9.53E-02 | 1.27E-01 | 1.27E+01 | 5.4  |
| 1.28E-01 | 1.71E-01 | 1.71E+01 | 5.6  |
| 1.67E-01 | 2.23E-01 | 2.23E+01 | 5.8  |
| 2.18E-01 | 2.90E-01 | 2.90E+01 | 6    |
| 2.68E-01 | 3.57E-01 | 3.57E+01 | 6.2  |
| 3.26E-01 | 4.35E-01 | 4.35E+01 | 6.4  |
| 4.00E-01 | 5.33E-01 | 5.33E+01 | 6.6  |
| 4.80E-01 | 6.40E-01 | 6.40E+01 | 6.8  |
| 5.75E-01 | 7.67E-01 | 7.67E+01 | 7    |
| 6.92E-01 | 9.23E-01 | 9.23E+01 | 7.2  |
| 8.55E-01 | 1.14E+00 | 1.14E+02 | 7.4  |
| 1.05E+00 | 1.40E+00 | 1.40E+02 | 7.6  |
| 1.25E+00 | 1.66E+00 | 1.66E+02 | 7.8  |
| 1.44E+00 | 1.92E+00 | 1.92E+02 | 8    |
| 1.79E+00 | 2.38E+00 | 2.38E+02 | 8.2  |
| 2.21E+00 | 2.95E+00 | 2.95E+02 | 8.4  |
| 2.63E+00 | 3.51E+00 | 3.51E+02 | 8.6  |
| 3.13E+00 | 4.17E+00 | 4.17E+02 | 8.8  |
| 4.05E+00 | 5.40E+00 | 5.40E+02 | 9    |
| 5.30E+00 | 7.06E+00 | 7.06E+02 | 9.2  |
| 7.27E+00 | 9.69E+00 | 9.69E+02 | 9.4  |
| 9.68E+00 | 1.29E+01 | 1.29E+03 | 9.5  |
| 1.25E+01 | 1.66E+01 | 1.66E+03 | 9.6  |
| 1.55E+01 | 2.07E+01 | 2.07E+03 | 9.7  |
| 2.54E+01 | 3.39E+01 | 3.39E+03 | 9.8  |
| 4.74E+01 | 6.32E+01 | 6.32E+03 | 9.9  |
| 1.08E+02 | 1.44E+02 | 1.44E+04 | 9.95 |
| 7.60E+02 | 1.00E+03 | 1.00E+05 | 10   |



### Analog Output calibration = 27 (Edwards APG100-M)


The APG100-M emulation provides a strongly none linear output with limited resolution in the low range and close to atmosphere

| Torr     | mbar     | Pascal   | Vout |
|----------|----------|----------|------|
| 7.50E-05 | 1.00E-04 | 1.00E-02 | 2    |
| 1.73E-04 | 2.31E-04 | 2.31E-02 | 2.05 |
| 4.66E-04 | 6.21E-04 | 6.21E-02 | 2.1  |
| 1.02E-03 | 1.36E-03 | 1.36E-01 | 2.2  |
| 2.23E-03 | 2.97E-03 | 2.97E-01 | 2.4  |
| 3.46E-03 | 4.61E-03 | 4.61E-01 | 2.6  |
| 4.88E-03 | 6.51E-03 | 6.51E-01 | 2.8  |
| 7.65E-03 | 1.02E-02 | 1.02E+00 | 3    |
| 1.10E-02 | 1.47E-02 | 1.47E+00 | 3.2  |
| 1.43E-02 | 1.91E-02 | 1.91E+00 | 3.4  |
| 2.21E-02 | 2.95E-02 | 2.95E+00 | 3.6  |
| 3.12E-02 | 4.16E-02 | 4.16E+00 | 3.8  |
| 4.21E-02 | 5.61E-02 | 5.61E+00 | 4    |
| 5.40E-02 | 7.20E-02 | 7.20E+00 | 4.2  |
| 6.71E-02 | 8.94E-02 | 8.94E+00 | 4.4  |
| 8.48E-02 | 1.13E-01 | 1.13E+01 | 4.6  |
| 1.09E-01 | 1.45E-01 | 1.45E+01 | 4.8  |
| 1.32E-01 | 1.76E-01 | 1.76E+01 | 5    |
| 1.67E-01 | 2.22E-01 | 2.22E+01 | 5.2  |
| 2.37E-01 | 3.16E-01 | 3.16E+01 | 5.4  |
| 3.10E-01 | 4.13E-01 | 4.13E+01 | 5.6  |
| 4.05E-01 | 5.40E-01 | 5.40E+01 | 5.8  |
| 5.12E-01 | 6.82E-01 | 6.82E+01 | 6    |
| 6.31E-01 | 8.41E-01 | 8.41E+01 | 6.2  |
| 7.95E-01 | 1.06E+00 | 1.06E+02 | 6.4  |
| 9.98E-01 | 1.33E+00 | 1.33E+02 | 6.6  |
| 1.20E+00 | 1.60E+00 | 1.60E+02 | 6.8  |
| 1.40E+00 | 1.87E+00 | 1.87E+02 | 7    |
| 1.70E+00 | 2.26E+00 | 2.26E+02 | 7.2  |
| 2.06E+00 | 2.75E+00 | 2.75E+02 | 7.4  |
| 2.43E+00 | 3.24E+00 | 3.24E+02 | 7.6  |
| 2.80E+00 | 3.73E+00 | 3.73E+02 | 7.8  |
| 3.29E+00 | 4.39E+00 | 4.39E+02 | 8    |
| 3.97E+00 | 5.29E+00 | 5.29E+02 | 8.2  |
| 4.70E+00 | 6.27E+00 | 6.27E+02 | 8.4  |
| 5.72E+00 | 7.63E+00 | 7.63E+02 | 8.6  |
| 7.04E+00 | 9.39E+00 | 9.39E+02 | 8.8  |
| 9.53E+00 | 1.27E+01 | 1.27E+03 | 9    |
| 1.25E+01 | 1.67E+01 | 1.67E+03 | 9.2  |
| 1.68E+01 | 2.24E+01 | 2.24E+03 | 9.4  |
| 2.16E+01 | 2.88E+01 | 2.88E+03 | 9.5  |
| 2.65E+01 | 3.53E+01 | 3.53E+03 | 9.6  |
| 3.36E+01 | 4.48E+01 | 4.48E+03 | 9.7  |
| 4.99E+01 | 6.65E+01 | 6.65E+03 | 9.8  |
| 1.06E+02 | 1.41E+02 | 1.41E+04 | 9.9  |
| 4.62E+02 | 6.16E+02 | 6.16E+04 | 9.95 |
| 7.60E+02 | 1.00E+03 | 1.00E+05 | 10   |




## Analog Output calibration = 28 (MKS 907)

| Torr     | mbar     | Pascal   | Vout  |
|----------|----------|----------|-------|
| 7.50E-04 | 1.00E-03 | 1.00E-01 | 0.387 |
| 1.50E-03 | 2.00E-03 | 2.00E-01 | 0.397 |
| 3.00E-03 | 4.00E-03 | 4.00E-01 | 0.418 |
| 4.50E-03 | 6.00E-03 | 6.00E-01 | 0.437 |
| 6.00E-03 | 8.00E-03 | 8.00E-01 | 0.456 |
| 7.50E-03 | 1.00E-02 | 1.00E+00 | 0.473 |
| 1.50E-02 | 2.00E-02 | 2.00E+00 | 0.551 |
| 2.25E-02 | 3.00E-02 | 3.00E+00 | 0.619 |
| 3.00E-02 | 4.00E-02 | 4.00E+00 | 0.679 |
| 3.75E-02 | 5.00E-02 | 5.00E+00 | 0.733 |
| 4.50E-02 | 6.00E-02 | 6.00E+00 | 0.783 |
| 5.25E-02 | 7.00E-02 | 7.00E+00 | 0.83  |
| 6.00E-02 | 8.00E-02 | 8.00E+00 | 0.874 |
| 6.75E-02 | 9.00E-02 | 9.00E+00 | 0.915 |
| 7.50E-02 | 1.00E-01 | 1.00E+01 | 0.955 |
| 1.50E-01 | 2.00E-01 | 2.00E+01 | 1.271 |
| 2.25E-01 | 3.00E-01 | 3.00E+01 | 1.508 |
| 3.00E-01 | 4.00E-01 | 4.00E+01 | 1.701 |
| 3.75E-01 | 5.00E-01 | 5.00E+01 | 1.864 |
| 4.50E-01 | 6.00E-01 | 6.00E+01 | 2.007 |
| 5.25E-01 | 7.00E-01 | 7.00E+01 | 2.133 |
| 6.00E-01 | 8.00E-01 | 8.00E+01 | 2.246 |
| 6.75E-01 | 9.00E-01 | 9.00E+01 | 2.348 |
| 7.50E-01 | 1.00E+00 | 1.00E+02 | 2.442 |
| 1.50E+00 | 2.00E+00 | 2.00E+02 | 3.083 |
| 2.25E+00 | 3.00E+00 | 3.00E+02 | 3.452 |
| 3.00E+00 | 4.00E+00 | 4.00E+02 | 3.698 |
| 3.75E+00 | 5.00E+00 | 5.00E+02 | 3.875 |
| 4.50E+00 | 6.00E+00 | 6.00E+02 | 4.009 |
| 5.25E+00 | 7.00E+00 | 7.00E+02 | 4.114 |
| 6.00E+00 | 8.00E+00 | 8.00E+02 | 4.198 |
| 6.75E+00 | 9.00E+00 | 9.00E+02 | 4.268 |
| 7.50E+00 | 1.00E+01 | 1.00E+03 | 4.327 |
| 1.50E+01 | 2.00E+01 | 2.00E+03 | 4.627 |
| 1.88E+01 | 2.50E+01 | 2.50E+03 | 4.695 |
| 2.25E+01 | 3.00E+01 | 3.00E+03 | 4.743 |
| 3.00E+01 | 4.00E+01 | 4.00E+03 | 4.805 |
| 3.75E+01 | 5.00E+01 | 5.00E+03 | 4.843 |
| 4.50E+01 | 6.00E+01 | 6.00E+03 | 4.872 |
| 5.25E+01 | 7.00E+01 | 7.00E+03 | 4.891 |
| 5.63E+01 | 7.50E+01 | 7.50E+03 | 4.898 |
| 6.00E+01 | 8.00E+01 | 8.00E+03 | 4.904 |
| 6.75E+01 | 9.00E+01 | 9.00E+03 | 4.914 |
| 7.50E+01 | 1.00E+02 | 1.00E+04 | 4.923 |
| 1.50E+02 | 2.00E+02 | 2.00E+04 | 4.987 |
| 1.88E+02 | 2.50E+02 | 2.50E+04 | 5.025 |
| 2.25E+02 | 3.00E+02 | 3.00E+04 | 5.071 |
| 3.00E+02 | 4.00E+02 | 4.00E+04 | 5.183 |
| 3.75E+02 | 5.00E+02 | 5.00E+04 | 5.301 |
| 4.50E+02 | 6.00E+02 | 6.00E+04 | 5.397 |
| 5.25E+02 | 7.00E+02 | 7.00E+04 | 5.478 |
| 5.63E+02 | 7.50E+02 | 7.50E+04 | 5.514 |
| 6.00E+02 | 8.00E+02 | 8.00E+04 | 5.548 |
| 6.75E+02 | 9.00E+02 | 9.00E+04 | 5.61  |
| 7.60E+02 | 1.00E+03 | 1.00E+05 | 5.666 |




## Analog Output calibration = 29 (K6080)

| Torr     | mbar     | Pascal   | Vout |
|----------|----------|----------|------|
| 7.50E-06 | 1.00E-05 | 1.00E-03 | 0.4  |
| 3.75E-05 | 5.00E-05 | 5.00E-03 | 0.4  |
| 7.50E-05 | 1.00E-04 | 1.00E-02 | 0.4  |
| 3.00E-04 | 4.00E-04 | 4.00E-02 | 0.4  |
| 6.00E-04 | 8.00E-04 | 8.00E-02 | 0.4  |
| 7.50E-04 | 1.00E-03 | 1.00E-01 | 0.41 |
| 3.00E-03 | 4.00E-03 | 4.00E-01 | 0.48 |
| 3.75E-03 | 5.00E-03 | 5.00E-01 | 0.5  |
| 6.75E-03 | 9.00E-03 | 9.00E-01 | 0.55 |
| 1.50E-02 | 2.00E-02 | 2.00E+00 | 0.61 |
| 3.75E-02 | 5.00E-02 | 5.00E+00 | 0.79 |
| 4.13E-02 | 5.50E-02 | 5.50E+00 | 1.1  |
| 4.50E-02 | 6.00E-02 | 6.00E+00 | 1.37 |
| 6.00E-02 | 8.00E-02 | 8.00E+00 | 1.6  |
| 7.50E-02 | 1.00E-01 | 1.00E+01 | 1.83 |
| 1.50E-01 | 2.00E-01 | 2.00E+01 | 2.64 |
| 2.60E-01 | 3.47E-01 | 3.47E+01 | 3.2  |
| 4.12E-01 | 5.50E-01 | 5.50E+01 | 3.71 |
| 5.31E-01 | 7.08E-01 | 7.08E+01 | 4    |
| 7.50E-01 | 1.00E+00 | 1.00E+02 | 4.45 |
| 1.14E+00 | 1.51E+00 | 1.51E+02 | 5    |
| 1.72E+00 | 2.29E+00 | 2.29E+02 | 5.44 |
| 3.00E+00 | 4.00E+00 | 4.00E+02 | 6.12 |
| 4.50E+00 | 6.00E+00 | 6.00E+02 | 6.8  |
| 4.88E+00 | 6.50E+00 | 6.50E+02 | 7.4  |
| 5.25E+00 | 7.00E+00 | 7.00E+02 | 7.96 |
| 6.00E+00 | 8.00E+00 | 8.00E+02 | 8.5  |
| 7.50E+00 | 1.00E+01 | 1.00E+03 | 9.01 |
| 1.50E+01 | 2.00E+01 | 2.00E+03 | 9.45 |
| 3.00E+01 | 4.00E+01 | 4.00E+03 | 9.7  |
| 4.50E+01 | 6.00E+01 | 6.00E+03 | 9.78 |
| 7.50E+01 | 1.00E+02 | 1.00E+04 | 9.85 |
| 1.50E+02 | 2.00E+02 | 2.00E+04 | 9.92 |
| 3.00E+02 | 4.00E+02 | 4.00E+04 | 9.95 |
| 4.50E+02 | 6.00E+02 | 6.00E+04 | 9.96 |
| 6.00E+02 | 8.00E+02 | 8.00E+04 | 9.98 |
| 7.60E+02 | 1.00E+03 | 1.00E+05 | 10   |




## Analog Output calibration = 30 (Inficon PEG100)

| Torr     | mbar     | Pascal   | Vout     |
|----------|----------|----------|----------|
| 1.00E-08 | 1.33E-08 | 1.33E-06 | 2.186111 |
| 1.00E-07 | 1.33E-07 | 1.33E-05 | 3.516111 |
| 1.00E-06 | 1.33E-06 | 1.33E-04 | 4.846111 |
| 1.00E-05 | 1.33E-05 | 1.33E-03 | 6.176111 |
| 1.00E-04 | 1.33E-04 | 1.33E-02 | 7.506111 |
| 5.00E-04 | 6.67E-04 | 6.67E-02 | 8.435741 |
| 1.00E-03 | 1.33E-03 | 1.33E-01 | 8.836111 |
| 1.00E-02 | 1.33E-02 | 1.33E+00 | 10.16611 |




### Analog Output calibration = 31 (Varian Eysys)

| Torr     | mbar     | Pascal   | Vout |
|----------|----------|----------|------|
| 1.00E-04 | 1.33E-04 | 1.33E-02 | 1    |
| 1.00E-03 | 1.33E-03 | 1.33E-01 | 2    |
| 1.00E-02 | 1.33E-02 | 1.33E+00 | 3    |
| 1.00E-01 | 1.33E-01 | 1.33E+01 | 4    |
| 1.00E+00 | 1.33E+00 | 1.33E+02 | 5    |
| 1.00E+01 | 1.33E+01 | 1.33E+03 | 6    |
| 1.00E+02 | 1.33E+02 | 1.33E+04 | 7    |
| 1.00E+03 | 1.33E+03 | 1.33E+05 | 8    |



### Analog Output calibration = 32 (Alcatel TA111)

| Torr     | mbar     | Pascal   | Vout |
|----------|----------|----------|------|
| 1.50E-03 | 2.00E-03 | 2.00E-01 | 0.1  |
| 2.25E-03 | 3.00E-03 | 3.00E-01 | 0.2  |
| 3.00E-03 | 4.00E-03 | 4.00E-01 | 0.3  |
| 3.75E-03 | 5.00E-03 | 5.00E-01 | 0.4  |
| 4.50E-03 | 6.00E-03 | 6.00E-01 | 0.5  |
| 5.25E-03 | 7.00E-03 | 7.00E-01 | 0.6  |
| 6.00E-03 | 8.00E-03 | 8.00E-01 | 0.7  |
| 6.75E-03 | 9.00E-03 | 9.00E-01 | 0.8  |
| 7.50E-03 | 1.00E-02 | 1.00E+00 | 0.9  |
| 8.25E-03 | 1.10E-02 | 1.10E+00 | 1    |
| 1.50E-02 | 2.00E-02 | 2.00E+00 | 1.8  |
| 2.25E-02 | 3.00E-02 | 3.00E+00 | 2.5  |
| 3.00E-02 | 4.00E-02 | 4.00E+00 | 3.15 |
| 3.75E-02 | 5.00E-02 | 5.00E+00 | 3.65 |
| 4.50E-02 | 6.00E-02 | 6.00E+00 | 4.1  |
| 5.25E-02 | 7.00E-02 | 7.00E+00 | 4.5  |
| 6.00E-02 | 8.00E-02 | 8.00E+00 | 4.85 |
| 6.75E-02 | 9.00E-02 | 9.00E+00 | 5.15 |
| 7.50E-02 | 1.00E-01 | 1.00E+01 | 5.4  |
| 1.50E-01 | 2.00E-01 | 2.00E+01 | 6.95 |
| 2.25E-01 | 3.00E-01 | 3.00E+01 | 7.7  |
| 3.00E-01 | 4.00E-01 | 4.00E+01 | 8.1  |
| 3.75E-01 | 5.00E-01 | 5.00E+01 | 8.4  |
| 4.50E-01 | 6.00E-01 | 6.00E+01 | 8.6  |
| 5.25E-01 | 7.00E-01 | 7.00E+01 | 8.75 |
| 7.50E-01 | 1.00E+00 | 1.00E+02 | 9    |
| 1.50E+00 | 2.00E+00 | 2.00E+02 | 9.2  |
| 2.25E+00 | 3.00E+00 | 3.00E+02 | 9.2  |




### Analog Output calibration = 33 (MKS 685)

$$P = 10^{(V_{out} - 4)}$$

$$V_{out} = 4 + \log_{10}(P)$$


| Torr     | mbar     | Pascal   | Vout |
|----------|----------|----------|------|
| 1.00E-05 | 1.33E-05 | 1.33E-03 | 1.00 |
| 1.00E-04 | 1.33E-04 | 1.33E-02 | 1.00 |
| 1.00E-03 | 1.33E-03 | 1.33E-01 | 1.00 |
| 1.00E-02 | 1.33E-02 | 1.33     | 2.00 |
| 1.00E-01 | 1.33E-01 | 13.3     | 3.00 |
| 1.00     | 1.33     | 133.3    | 4.00 |
| 10.0     | 13.3     | 1333.2   | 5.00 |
| 100      | 133.3    | 1.33E+04 | 6.00 |
| 1000     | 1333.2   | 1.33E+05 | 7.00 |




## MicroPirani gas dependence

The 972B MicroPirani is based on measurement of thermal conductivity and consequently its reading depends on gas and gas concentration. The 972B has calibration curves for a number of common gases. For gas setup refer to gas calibration on page 24.


The 972B is per factory default calibrated for Nitrogen gas and below is showed the 972B Nitrogen MicroPirani reading in different gas types.




## Helium gas dependence



### Argon gas dependence



### Hydrogen gas dependence



## Query Command list (See the EtherCAT Communications Protocol manual #20003335)

### Communication information

| Command     | Response       | Explanation                                                              |
|-------------|----------------|--------------------------------------------------------------------------|
| @xxxBR?;FF  | @xxxACK9600;FF | Communication baud rate (4800, 9600, 19200, 38400, 57600, 115200,230400) |
| @xxxAD?;FF  | @xxxACK253;FF  | Transducer communication address (001 to 253)                            |
| @xxxRSD?;FF | @xxxACKON;FF   | Communication delay between receive and transmit sequence.               |

### Pressure reading

| Command     | Response           | Explanation                                                   |
|-------------|--------------------|---------------------------------------------------------------|
| @xxxPR1?;FF | @xxxACK1.23E-3;FF  | MicroPirani sensor pressure as 3 digit floating point value.  |
| @xxxPR2?;FF | @xxxACK1.23E-5;FF  | Cold Cathode sensor pressure as 3 digit floating point value. |
| @xxxPR3?;FF | @xxxACK1.23E-5;FF  | Combined Cold Cathode and MicroPirani pressure (3 digits).    |
| @xxxPR4?;FF | @xxxACK1.234E-3;FF | Combined Cold Cathode and MicroPirani pressure (4 digits).    |
| @xxxPR5?;FF | @xxxACK1.234E-3;FF | Cold Cathode sensor pressure as 3 digit floating point value. |

### Setpoint information

| Command                                   | Response          | Explanation                                                                                                                                                              |
|-------------------------------------------|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| @xxxSS1?;FF<br>@xxxSS2?;FF<br>@xxxSS3?;FF | @xxxACKSET;FF     | Setpoint relay 1-3 status (SET=Relay energized / CLEAR=Relay deenergized)                                                                                                |
| @xxxSP1?;FF<br>@xxxSP2?;FF<br>@xxxSP3?;FF | @xxxACK1.00E-2;FF | Setpoint 1-3 switch value.                                                                                                                                               |
| @xxxSH1?;FF<br>@xxxSH2?;FF<br>@xxxSH3?;FF | @xxxACK1.10E-2;FF | Setpoint 1-3 hysteresis switch value.                                                                                                                                    |
| @xxxEN1?;FF<br>@xxxEN2?;FF<br>@xxxEN3?;FF | @xxxACKOFF;FF     | Setpoint 1-3 enable status ( OFF, PIR=MicroPirani, CC=Cold Cathode or CMB=Combined)                                                                                      |
| @xxxSD1?;FF<br>@xxxSD2?;FF<br>@xxxSD3?;FF | @xxxACKBELOW;FF   | Setpoint relay direction (ABOVE or BELOW)<br>If set to above relay will be energized above setpoint value. If set to below relay will be energized below setpoint value. |

### Transducer information

| Command      | Response              | Explanation                                             |
|--------------|-----------------------|---------------------------------------------------------|
| @xxxMD?;FF   | @xxxACK972B;FF        | Model number (972B)                                     |
| @xxxDT?;FF   | @xxxACKDualMag;FF     | Device type name (MicroPirani)                          |
| @xxxMF?;FF   | @xxxACKMKS;FF         | Manufacturer name (MKS)                                 |
| @xxxHV?;FF   | @xxxACKA;FF           | Hardware version                                        |
| @xxxFV?;FF   | @xxxACK1.12;FF        | Firmware version                                        |
| @xxxSN?;FF   | @xxxACK08350123456;FF | Serial number                                           |
| @xxxSW?;FF   | @xxxACKON;FF          | Switch enable                                           |
| @xxxTIM?;FF  | @xxxACK123;FF         | Time on (hours of operation )                           |
| @xxxTIM2?;FF | @xxxACK24;FF          | Cold cathode high voltage time on (hours of operation ) |
| @xxxTIM3?;FF | @xxxACK1.00E-2;FF     | Cold cathode pressure dose                              |
| @xxxTEM?;FF  | @xxxACK2.50E+1;FF     | MicroPirani sensor temperature                          |
| @xxxUT?;FF   | @xxxACKVACUUM1;FF     | User programmed text string (user tag)                  |
| @xxxT?;FF    | @xxxACKO;FF           | Transducer status check                                 |

### Calibration and adjustment information

| Command      | Response           | Explanation                                                                                                |
|--------------|--------------------|------------------------------------------------------------------------------------------------------------|
| @xxxU?;FF    | @xxxACKTORR;FF     | Pressure unit setup (Torr, mbar or Pascal)                                                                 |
| @xxxGT?;FF   | @xxxACKNITROGEN;FF | MicroPirani sensor calibration gas (Nitrogen, Air, Argon, Helium, Hydrogen, H2O, Neon, CO2, Xenon)         |
| @xxxVAC?;FF  | @xxxACK5.12E-5;FF  | Provides delta pressure value between current MicroPirani vacuum zero adjustment and factory calibration.  |
| @xxxVAC3?;FF | @xxxACK5.12E-8;FF  | Provides delta pressure value between current cold cathode vacuum zero adjustment and factory calibration. |
| @xxxATM?;FF  | @xxxACK1.22E+1;FF  | Provides pressure factor value between current atmospheric adjustment and factory calibration.             |
| @xxxCFS?;FF  | @xxxACK1.01E-3;FF  | Provides pressure factor value between current Cold cathode full scale adjustment and factory calibration. |
| @xxxAO1?;FF  | @xxxACK30;FF       | Analog voltage output 1: Pressure assignment and calibration. (first                                       |

|             |              |                                                                                                                                           |
|-------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------|
|             |              | digit is pressure assignment, second and third digit is calibration)                                                                      |
| @xxxAO2?;FF | @xxxACK30;FF | Analog voltage output 2: Pressure assignment and calibration. (first digit is pressure assignment, second and third digit is calibration) |

## Setup and configuration command list

### Setpoint setup and configuration (See the EtherCAT Communications Protocol manual #20003335)

| Command                                                        | Response          | Explanation                                                                                                                                                                 |
|----------------------------------------------------------------|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| @xxxSP1!2.00E+1;FF<br>@xxxSP2!2.00E+1;FF<br>@xxxSP3!2.00E+1;FF | @xxxACK2.00E+1;FF | Setpoint 1-3 switch value.                                                                                                                                                  |
| @xxxSH1!5.00E+1;FF<br>@xxxSH2!5.00E+1;FF<br>@xxxSH3!5.00E+1;FF | @xxxACK5.00E+1;FF | Setpoint 1-3 hysteresis switch value.                                                                                                                                       |
| @xxxEN1!ON;FF<br>@xxxEN2!ON;FF<br>@xxxEN3!ON;FF                | @xxxACKON;FF      | Setpoint 1-3 enable status (ON or OFF)                                                                                                                                      |
| @xxxSD1!BELOW;FF<br>@xxxSD2!BELOW;FF<br>@xxxSD3!BELOW;FF       | @xxxACKBELOW;FF   | Setpoint relay direction (ABOVE or BELOW)<br>If set to above relay will be energized above setpoint value.<br>If set to below relay will be energized below setpoint value. |

### Communication setup

| Command         | Response        | Explanation                                                                   |
|-----------------|-----------------|-------------------------------------------------------------------------------|
| @xxxBR!19200;FF | @xxxACK19200;FF | Set communication Baud rate (4800, 9600, 19200, 38400, 57600, 115200, 230400) |
| @xxxAD!123;FF   | @xxxACK123;FF   | Set Transducer communication address (001 to 253)                             |
| @xxxRSD!OFF;FF  | @xxxACKOFF;FF   | Turn on or off communication delay between receive and transmit sequence.     |

### Calibration and adjustment

| Command            | Response          | Explanation                                                                                             |
|--------------------|-------------------|---------------------------------------------------------------------------------------------------------|
| @xxxU!MBAR;FF      | @xxxACKMBAR;FF    | Set pressure unit setup (Torr, mbar, Pascal)                                                            |
| @xxxGT!ARGON;FF    | @xxxACKARGON;FF   | Set MicroPirani sensor calibration gas. (Nitrogen, Air, Argon, Helium, Hydrogen, H2O, Neon, CO2, Xenon) |
| @xxxVAC!;FF        | @xxxACK;FF        | Executes MicroPirani zero adjustment                                                                    |
| @xxxATM!7.60E+2;FF | @xxxACK;FF        | Executes MicroPirani full scale atmospheric adjustment.                                                 |
| @xxxVAC3!;FF       | @xxxACK;FF        | Executes Cold Cathode zero adjustment                                                                   |
| @xxxCFS!4.00E-3;FF | @xxxACK;FF        | Executes Cold Cathode full scale adjustment.                                                            |
| @xxxAO1!10;FF      | @xxxACK10;FF      | Set analog voltage output 1 calibration.                                                                |
| @xxxAO2!10;FF      | @xxxACK10;FF      | Set analog voltage output 2 calibration.                                                                |
| @xxxMZL!1.00E-4;FF | @xxxACK1.00E-4;FF | MicroPirani auto zero limit                                                                             |

### Information setup

| Command           | Response          | Explanation             |
|-------------------|-------------------|-------------------------|
| @xxxUT!DUALMAG;FF | @xxxACKDUALMAG;FF | Set transducer user tag |

### User Switch

| Command      | Response     | Explanation                  |
|--------------|--------------|------------------------------|
| @xxxSW!ON;FF | @xxxACKON;FF | Enable / disable user switch |

### Cold Cathode setup

| Command            | Response          | Explanation                                   |
|--------------------|-------------------|-----------------------------------------------|
| @xxxSLC!5.00E-4;FF | @xxxACK5.00E-4;FF | CC turn on pressure                           |
| @xxxSHC!8.00E-4;FF | @xxxACK8.00E-4;FF | CC turn off pressure                          |
| @xxxSLP!1.00E-4;FF | @xxxACK1.00E-4;FF | Setpoint low CC/MP integration                |
| @xxxSHP!4.00E-4;FF | @xxxACK4.00E-4;FF | Setpoint high CC/MP integration               |
| @xxxPRO!240;FF     | @xxxACK240;FF     | Cold cathode protect setpoint time and enable |
| @xxxPD!1.00E-2;FF  | @xxxACK1.00E-2;FF | Cold cathode pressure dose setpoint           |

xxx = Transducer communication address (001 to 253. Broadcast addresses: 254, 255)

### Firmware upgrades (RS-232 only)

The 910 firmware can be upgraded by the user. The following procedure should be used:

1. Install the 900 Series firmware download software from the Documentation CD or download from [www.mksinst.com/vtsw/](http://www.mksinst.com/vtsw/).
2. Turn power off.
3. Hold down the User switch while turning power on.
4. Release the User switch.
5. Run the 900 Series firmware download software and start download.



**Transducers with RS-485 interface cannot be firmware upgraded by the user. Transducers with EtherCAT interface can be upgraded; contact MKS Customer Service for details.**

---

## FAQ (Frequently Asked Questions)

### Applications

**Q:** *Can the transducer and sensor element continuously withstand vibrations from a mechanical fore-pump.*

**A:** Yes – the MEMS MicroPirani sensor element and cold cathode sensor can withstand continuous vibrations.

**Q:** *Is the transducer compatible with fluorine gases?*

**A:** No – the 972B is not intended for use in aggressive environments like semiconductor etch applications.

**Q:** *When the transducer is pumped down and isolated by closing a valve the pressure is raising. Is the transducer leaking?*

**A:** Not likely - when a confined space is evacuated and the pumping is stopped the pressure will rise because of out gassing, mainly by water vapor. The pressure can easily rise to a few Torr over time.

**Q:** *When the transducer is leak checked on a helium leak detector, leak reading is building up slowly after approximately 30 seconds. Is the transducer leaking?*

**A:** No - the internal sealing of the 972B transducer uses elastomer Viton sealing and consequently helium molecules can penetrate through the Viton material and cause slow increase of helium leak readout. If a leaking transducer is tested directly on a helium leak detector the leak is almost instantly displayed.

**Q:** *Can the transducer be mounted in any orientation?*

**A:** Yes - the transducer can be mounted in any orientation without compromise of performance or calibration. However it is recommended not to mount the transducer with the flange port facing upwards to avoid contamination like particulates or liquids from entering the device. See page 8.

**Q:** *Can the transducer withstand instant ventilation?*

**A:** Yes - the MicroPirani and Cold cathode sensor elements are extremely robust to mechanical forces and can withstand continuously pressure cycles and instant air ventilation. It's not recommended to perform instant ventilation when the Cold Cathode is turned on.

**Q:** *Can I connect a valve to be controlled by the transducer relay contact?*

**A:** Driving inductive loads such as valves requires special precautions. Refer to pages 15 & 16.

**Q:** *How many pressure cycles can the transducer withstand?*

**A:** Both the MicroPirani and Cold Cathode sensor elements are robust to pressure changes and there are no limits on the number of pressure cycles. In applications where fast pressure cycles occur, the Cold Cathode sensor can be sputtered and this can lead to change of accuracy.

**Q:** *The Cold Cathode sensor chamber has changed color, Why?*

**A:** If the Cold Cathode is operated at high pressure ( $>1.00E-4$  Torr) the inside walls of the cold cathode ionization cell can be sputtered. This will change the color of the internal measuring chamber and can also result in change of measuring accuracy.

### Analog output

**Q:** *What is the update rate of the analog output?*

**A:** 16 times per second.

**Q:** *What is the maximum length of analog output cable?*

**A:** The length of analog cable depends on cable quality and electrical noise environment, but cable lengths up to 100 m do not normally require any special precautions other than the cable must be screened.

**Q:** *The digital reading is correct but the analog output reading has some deviation from actual pressure?*

**A:** Check that the analog out is connected to a floating input and not an input that is connected to ground. If connected analog out return is connected to ground, the supply current will flow in the signal line and cause voltage drop and ground looping.

### Digital output

**Q:** *How fast can I request pressure measurements via the digital interface?*

**A:** 10 times per second is the fastest recommended pressure request frequency.

---

**Q:** *How long is the waiting time from turning power on to valid measuring values?*

**A:** The power on sequence is approximately 2 seconds. The status LED will illuminate red during the power up sequence and the digital interface will not reply to commands. On EtherCAT units the LED blinks GREEN when pressure can be read.

**Q:** *The first character is sometimes lost in the transducer digital communication reply?*

**A:** This can be caused by too fast transducer communication reply. See RS delay command description page 14.

**Q:** *Is it necessary to use the ground wire between RS-485 communication equipment and transducer?*

**A:** Yes - both RS-232 and RS-485 communication requires a 3 wire connection between transducer and communication equipment.

### **Calibration and adjustment**

**Q:** *How often does the transducer require calibration or Zero adjustment?*

**A:** It depends on the application and pressure range but in many applications user adjustment is never required. Factors that temporarily or permanently can influence the measuring performance are contamination, corrosion, heat and electronic interference. The MicroPirani is automatically zero adjusted whenever the pressure measured by the cold cathode is below the MicroPirani zero limit.

**Q:** *How long is the warm up time before obtaining reliable measurements from the transducer?*

**A:** The small mass of the MicroPirani sensor element ensures short sensor warm up time. Reliable measurements are typically available within 1 minute. The cold cathode has a stabilization of a few minutes after turning the high voltage on.

**Q:** *Will the transducer retain user calibration after power is shut off?*

**A:** Yes - all transducer parameters including calibration data are stored internally in the transducer non volatile memory.

**Q:** *The 972B reads 900 Torr at atmospheric pressure of 760 Torr.*

**A:** The transducer is based on measurement of thermal conductivity and if exposed to ambient pressure the higher thermal conductivity of air will cause the transducer to read higher values. The transducer is per factory default calibrated with Nitrogen.

### **Service and repair**

**Q:** *Can the sensor element be changed if contaminated?*

**A:** No - the sensor elements cannot be changed without its measuring electronics. The transducer flange assembly can be exchanged with the 972B repair kit. Refer to Service and Repair page 57.

**Q:** *How often does the Cold Cathode sensor require cleaning?*

**A:** Contaminants such as oil vapors from oil lubricated for pump will cause carbonaceous deposits which will affect sensitivity of the gauge. The cleaning interval depends on contamination type and pressure range, but can be down to a few hundred of hours of Cold Cathode operation time. Cold Cathode time on can be read by using the command: @254TIM2?;FF

The anode module and screens can be removed and mechanical polished or replaced.

**Q:** *+24 VDC supply voltage has been connected to analog output+. Is the transducer damaged?*

**A:** Likely - the analog output is not protected against applying power to the output pin.

**Q:** *Reverse voltage has been connected to power supply input. Is the transducer damaged?*

**A:** Not likely – the transducer power supply circuit has reverse voltage and over voltage protection however. MKS cannot guarantee that the transducer will not be damaged.

**Q:** *The status LED is constantly illuminating red. (not applicable to EtherCAT units; see the EtherCAT Communication Protocol Manual 20003335)*

**A:** The red status indicates a defect MicroPirani sensor element most likely damaged by corrosion or contamination. Refer to Service and Repair page 57.

## Trouble shooting

| Symptom                                                                                                               | Possible Cause/Remedy                                                                                                                                                                                                                                                                                                                                                                         |
|-----------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>No digital communication</b>                                                                                       | <ul style="list-style-type: none"> <li>- Check electrical connections for RS-232/RS-485 units (3 wires from transducer to communication equipment)</li> <li>- Transducer and communication equipment baud rate matches</li> <li>- Use of incorrect transducer address. Try address 254</li> <li>- Attention characters missing (@)</li> <li>- Termination characters missing (;FF)</li> </ul> |
| <b>NAK180 is received when transmitting setpoint commands</b>                                                         | <ul style="list-style-type: none"> <li>- The transducer setup is locked. Refer to disable lock procedure page 27.</li> </ul>                                                                                                                                                                                                                                                                  |
| <b>Incorrect pressure value</b>                                                                                       | <ul style="list-style-type: none"> <li>- Other gas present than transducer gas setting or trace of gas.</li> <li>- Contaminated sensor. Transducer repair required.</li> <li>- Corroded sensor. Transducer repair required.</li> </ul>                                                                                                                                                        |
| <b>Incorrect pressure value at low pressure.</b>                                                                      | <ul style="list-style-type: none"> <li>- Contaminated sensor. Transducer repair required.</li> <li>- Corroded sensor. Transducer repair required.</li> <li>- Incorrect Vac adjustment has been executed.</li> <li>- Transducer exposed to heat or cooling air stream.</li> </ul>                                                                                                              |
| <b>Incorrect pressure value at high pressure.</b>                                                                     | <ul style="list-style-type: none"> <li>- Contaminated sensor. Transducer repair required.</li> <li>- Corroded sensor. Transducer repair required.</li> <li>- Incorrect ATM adjustment has been executed.</li> <li>- Other gas or gas trace present than transducer gas setting.</li> </ul>                                                                                                    |
| <b>Cold Cathode does not provide measurements.</b>                                                                    | <ul style="list-style-type: none"> <li>- If the Cold cathode is turned on at low pressure <math>&lt;1.00E-7</math> Torr or is contaminated, a delay can occur from turning on high voltage to when the ionization begins. At low pressure the delay can be several minutes.</li> </ul>                                                                                                        |
| <b>Cold Cathode value is lower than actual pressure.</b>                                                              | <ul style="list-style-type: none"> <li>- If the Cold Cathode sensor has been operated at too high pressure or exposed to fast pressure cycles the sensor can be sputtered. Sputtering of sensor will normally provide lower reading than actual pressure.</li> </ul>                                                                                                                          |
| <b>Setpoint relay does not trip.</b><br><i>(not applicable to EtherCAT units)</i>                                     | <ul style="list-style-type: none"> <li>- Setpoint not enabled.</li> <li>- Setpoint value not set to proper value.</li> <li>- Setpoint direction is different than the user expects.</li> <li>- Check electrical connection.</li> <li>- Check part number to see if transducer has setpoint relays.</li> </ul>                                                                                 |
| <b>No analog output</b>                                                                                               | <ul style="list-style-type: none"> <li>- Power supply turned off.</li> <li>- Check electrical connections.</li> </ul>                                                                                                                                                                                                                                                                         |
| <b>Status LED illuminating red.</b><br><i>(for EtherCAT units, see the EtherCAT Status Indicator table on page 7)</i> | <ul style="list-style-type: none"> <li>- Sensor element defect. Refer to Service and Repair page 57.</li> </ul>                                                                                                                                                                                                                                                                               |

## Service and Repair

The 972B Transducer repair kit includes the flange and calibrated sensor (1) electronics and can be used for quick and easy customer in-field service of the 972B Transducer. After the installation of the repair kit the transducer will be operating as a new transducer.

**NOTE:** The 9XXX-XREP kits are to be used for RS-232/485 configurations only.



**Transducers with integrated display (P/N: 901P-xxxx4 and 901P-xxxx6) can be repaired ONLY be an MKS service technician; contact MKS Customer Service for details.**


**Transducers with an EtherCAT sensor can be repaired ONLY be an MKS service technician; contact MKS Customer Service for details.**

### 972B Transducer repair kit

| Part number | Description                            |
|-------------|----------------------------------------|
| 972B-2NT    | 972B Sensor repair kit. KF25 flange    |
| 972B-7NT    | 972B Sensor repair kit. CF2.75" flange |
| 972B-9NT    | 972B Sensor repair kit. KF40 flange    |



Before disassembling the transducer take precautions to avoid static discharge which can damage the electronics. Use grounded wrist band if available.



### Installing the 972B transducer repair kit

1. Turn power off and disconnect the cable.
2. Remove the transducer from the vacuum system.
3. Unscrew the two hex screws (4) at the DSUB connector using a 5mm hex wrench.
4. Use a paper clip, a small screwdriver or similar tool to press down the two mounting tabs (1a) on the side.
5. Carefully remove the enclosure (3).

- 
6. Remove the top circuit board (2).
  7. Mount the top circuit board (2) on the new 972B Sensor repair kit flange and make sure the printed circuit board alignment identifications match the two boards.
  8. Carefully assemble the enclosure (3) and make sure the mounting tabs (1a) click out.
  9. Install the two hex screws (4).
  10. If required, re-enter transducer setpoints, gas type and other applications parameters.



**The 972B Sensor repair kit flange does not have customer setup or configuration parameters (such as setpoint settings); it is always delivered with factory default parameters.**


**The exchanged flange assembly should not be disposed in the normal unsorted waste stream. It should be deposited at an appropriate collection point or facility to enable recovery or recycling.**

## 972B Cold cathode maintenance

When a Cold Cathode sensor is turned on and operated at pressures higher than  $1.0E-4$  Torr, the inside wall of the ionization chamber can be sputtered by ions formed by the high energetic plasma. Inert gases like argon are easier to ionize and consequently the sputter effect is more significant in such environment.

If the transducer is contaminated, the pressure measurement will typically be lower than actual pressure. Sputtering can also be visually detected since the inside wall of the transducer changes color. When operated in oil lubricated pumping systems, hydrocarbons can cause contamination of cold cathode measuring cell. The cold cathode hour counter and pressure dose can be used to determine if service is required. (See pages 22 and 23)

If sputtering or contamination occurs, the ionization cell kit or anode module can be changed from the flanges side without disassembling of the transducer. The anode module and cell kit (p/n: 970BNT-KIT) is available as spare parts. The basic accuracy of the cold cathode sensor can change after replacement of anode. The cell kit and anode module can also be cleaned by mechanical polishing.




P/N: 970BNT-KIT



Do not touch the cell kit, anode module, screen, screws or clip ring by hand. If items are accidentally touched by hand, use alcohol to clean the items.

### Changing the Cell kit

1. Turn off power and disconnect the cable.
2. Remove the transducer from the vacuum system.
3. Remove the clip ring (1) using a clip ring remove/insert tool (p/n: 100017193).
4. Remove the screen (2).
5. Unscrew the Torx (T6) screws (3) at the rear screen (4).
6. Remove the rear screen (4).
7. Insert the new screen (Do not touch by hand).
8. Insert the Torx (T6) screw (3) and tighten.
9. Insert the front screen (2) and clip ring (1).



### Changing the Anode

1. Remove cell kit (steps 1-6, above).
2. Unscrew the 3 screws at the anode module.
3. Remove the anode module and clean module or insert new.
4. Insert the anode module screw and DO NOT tighten. After all screws are inserted carefully tighten the screw a little and move on to the next one. Continue to tighten the screws one by one until all tight.
5. Perform leak testing of transducer.
6. Insert cell kit (steps 7-9, above).

### Cleaning anode module and screens

---

Contaminated parts can be cleaned by mechanical polishing or ultra sonic cleaned followed by alcohol degreasing. Make sure that all parts are clean and remove any discoloring of the stainless steel and titanium parts. Alternatively the anode module or screens can be replaced with new parts.

---

## Specifications

Measuring range (N<sub>2</sub> and Air): 1×10<sup>-8</sup> Torr to atmosphere

### MicroPirani

|                                                 |                                                |                  |
|-------------------------------------------------|------------------------------------------------|------------------|
| Accuracy <sup>(1)</sup> (N <sub>2</sub> )       | 1×10 <sup>-4</sup> to 1×10 <sup>-3</sup> Torr: | ±10% of reading  |
|                                                 | 1×10 <sup>-3</sup> to 100 Torr:                | ± 5% of reading  |
|                                                 | 100 Torr to Atm.:                              | ± 25% of reading |
| Repeatability <sup>(1)</sup> (N <sub>2</sub> ): | 1×10 <sup>-3</sup> to 100 Torr:                | ± 2% of reading  |

### Cold cathode

|                                 |                                                |                 |
|---------------------------------|------------------------------------------------|-----------------|
| Accuracy Cathode <sup>(1)</sup> | 1×10 <sup>-8</sup> to 1×10 <sup>-3</sup> Torr: | ±30% of reading |
|---------------------------------|------------------------------------------------|-----------------|

Supply Voltage: 9 – 30 VDC

Power consumption: < 2 Watt

Fuse (thermal recoverable): 200 mA

Analog output (MKS standard): 1-9 VDC

Analog output 1 resolution: 16 bit

Analog output 2 resolution: (N/A EtherCAT) 12 bit

Analog output impedance: 100 Ω

Analog output update rate: 16 Hz

Setpoint relay range: (*setpoints N/A in EtherCAT*) 1×10<sup>-8</sup> to 500 Torr

Setpoint relay contact rating: 1A / 30 VDC/ac (resistive load)

Setpoint relay contact resistance: 100 mΩ (max)

Setpoint relay contact endurance (30VDC/1A load): 100.000 (min)

Setpoint relay contact endurance (30VDC/0.2A load): 2.000.000 (min)

Setpoint relay response time: <100 ms

Materials exposed to vacuum: 304 and 403 stainless steel, silicon, SiO<sub>2</sub>, SiN<sub>4</sub>, Gold, Viton®, Cu-Ni and Ag-Cu alloy, epoxy resin, ceramic, titanium

|                  |                |                      |
|------------------|----------------|----------------------|
| Internal volume: | KF25 flange    | 28.6 cm <sup>3</sup> |
|                  | CF2.75" flange | 20.7 cm <sup>3</sup> |
|                  | KF40 flange    | 21.7 cm <sup>3</sup> |

Housing material: Stainless steel 304

Flange material: Stainless steel 304

|         |                |       |
|---------|----------------|-------|
| Weight: | KF25 flange    | 360 g |
|         | CF2.75" flange | 570 g |
|         | KF40 flange    | 390 g |

Operating temperature: 0 to 40 °C (32 to 104 °F)

Bake out temperature (Power off): 80 °C (176 °F)


Humidity: 0 – 95% Non-condensing

Ingress Protection Rating: IP40 / IP54<sup>(2)</sup>


(1) Accuracy and repeatability are typical values measured in Nitrogen atmosphere after zero adjustment at ambient temperature.

(2) Special 972B version available with IP 54 rating.


## 972B Transducer Dimensions



### 972B Transducer Standard Model Dimensions



### 972B Transducer Digital Display Model Dimensions



### 972B Transducer EtherCAT Model Dimensions

## Accessories and replacement part numbers

### PDR900 controller

| Part number  | Description       | Interface                          |
|--------------|-------------------|------------------------------------|
| PDR900-12-EU | PDR900 Controller | EU Schuko power cable              |
| PDR900-12-US | PDR900 Controller | US power cable                     |
| PDR900-12-UK | PDR900 Controller | UK power cable                     |
| PDR900-12-JP | PDR900 Controller | JP power cable. mbar / Pascal unit |



### PDR900 Transducer Cables for 972B (15 pin HD DSUB)

For transducer part number: 972B-x102x, 972B-x103x, 972B-x105x

| Part number | Description  | Interface |
|-------------|--------------|-----------|
| 100013620   | 3 m (10ft.)  | RS-232    |
| 100013621   | 5 m (16ft.)  | RS-232    |
| 100013622   | 7.6m (25ft.) | RS-232    |
| 100013623   | 10 m (33ft.) | RS-232    |

For transducer part number: 972B-x202x, 972B-x203x, 972B-x205x

| Part number | Description  | Interface |
|-------------|--------------|-----------|
| 100013671   | 3 m (10ft.)  | RS-485    |
| 100013672   | 5 m (16ft.)  | RS-485    |
| 100013673   | 7.6m (25ft.) | RS-485    |
| 100013674   | 10 m (33ft.) | RS-485    |

### PDR900 Connectors & cables

| Part number | Description                    |
|-------------|--------------------------------|
| 100010757   | Setpoint Relay 3 pin connector |
| 100013638   | Analog output 8 pin connector  |

### 972B Transducer repair kit (RS-232 & RS-485 only)

| Part number | Description                                         |
|-------------|-----------------------------------------------------|
| 972B-2NT    | 972B Sensor repair kit. KF25 flange                 |
| 972B-7NT    | 972B Sensor repair kit CF2.75"flange                |
| 972B-9NT    | 972B Sensor repair kit. KF40 flange                 |
| 970BNT-KIT  | Rebuild kit for 970 Series cold cathode Transducers |
| 100017192   | Torx Driver, for Anode change                       |
| 100017193   | Circlip ring plier                                  |

---

## PDR 900 Display and power supply

(N/A EtherCAT)

- Plug and play readout for 900 Series transducers
- The easy way for setup and configuration
- Data logger tool for data analysing



See more on: [www.mksinst.com/pdr900](http://www.mksinst.com/pdr900)

---

## 900 Series VacuumLog software

(N/A EtherCAT)

- Data logger software
- Pressure curve plotting
- Rate of raise diagnostic tool
- Pump down monitoring
- Export of data to Excel spread sheet
- Windows 7 compatible

Free version available at:

<http://www.mksinst.com/vtsw/>



# Index

|                                          |        |                                      |            |
|------------------------------------------|--------|--------------------------------------|------------|
| Accessories and replacement part numbers | 67     | Magnetic interference                | 4          |
| Accuracy                                 | 64     | Manufacturer                         | 31         |
| Accuracy and repeatability               | 26     | Model                                | 31         |
| Addressing                               | 16     | Moducell 325                         | 39         |
| Analog output                            | 32, 58 | NAK Code                             | 15         |
| Applications                             | 7, 58  | NAK180                               | 18, 30, 60 |
| Argon gas                                | 54     | Operating temperature                | 64         |
| Atmospheric adjustment                   | 28     | Part number                          | 6          |
| Auto Zero Adjustment                     | 27     | Part Number                          | 31         |
| Bake out                                 | 9      | PDR900                               | 67, 68     |
| Bake out temperature                     | 64     | PDR900 controller relays             | 17         |
| Baud rate                                | 16     | Pressure output                      | 22         |
| Calibration and adjustment               | 26     | Process compatibility                | 9          |
| Calibration certificate                  | 67     | Query Command list                   | 55         |
| CE marking                               | 5      | Repair                               | 61         |
| Cold Cathode setup                       | 24     | Repeatability                        | 64         |
| Communication delay                      | 16     | RS-232 user interface                | 13         |
| Communication Protocol                   | 15     | RS-485 user interface                | 13         |
| Communication software                   | 15     | Safety information                   | 4          |
| Contamination                            | 9      | Sensor Check                         | 31         |
| Device Type                              | 31     | Sensor technology                    | 7          |
| Display                                  | 20     | Serial Number                        | 31         |
| Disposal                                 | 7      | Serial user interface                | 13         |
| Dual Analog output                       | 34     | Service and repair                   | 4, 59, 61  |
| Explosive Environments                   | 4, 9   | Setpoint functionality               | 17         |
| Factory default                          | 29     | Setpoint relay                       | 17         |
| Firmware upgrade                         | 8, 57  | Setup and configuration command list | 56         |
| Firmware upgrades (RS-232 only)          | 57     | Specifications                       | 64         |
| Firmware Version                         | 31     | Supply Voltage                       | 64         |
| Frequently Asked Questions               | 58     | Temperature                          | 9, 31      |
| Fuse                                     | 4, 64  | termination resistor                 | 13         |
| Gas calibration                          | 26     | Time ON                              | 31         |
| gas dependence                           | 52     | Transducer installation (electrical) | 10         |
| Grounding                                | 4      | Transducer installation (mechanical) | 9          |
| Hardware Version                         | 31     | Trouble shooting                     | 60         |
| Helium gas                               | 52     | Unit calibration                     | 26         |
| Hydrogen gas                             | 54     | Unpacking                            | 6          |
| Inductive relay load                     | 17     | User Switch                          | 8, 30      |
| Input/Output Wiring                      | 11     | Vacuum connections                   | 9          |
| Internal volume                          | 64     | Vibrations                           | 9          |
| LED Status Indicator                     | 8      | Zero Adjustment                      | 27         |
| lock function                            | 30     |                                      |            |





## **972B DualMag™**

Vacuum Pressure Transducer  
**Models with RS-232/RS-485,  
EtherCAT®, or Digital Display**

## **Operation and Installation Manual**

P/N: 100017133  
972B DualMag™ Transducer  
Operation and Installation Manual  
Revision: K, February 2020