

## 221B Capacitance Manometer Pin-outs

14-pin Amp Connector

Pin	Description
1	Chassis Ground
2	DC Common
3	No Connection
4	No Connection
5	+15 Volt Input
6	-15 Volt Input
7	DC Output Signal
8	Chassis Ground
9	DC Common
10-14	No Connection