



AT TEMP/HEATER FAILURE INDICATORS



STANDARD CONFIGURATION



Dimensional Drawing —
 Note: Unless otherwise specified,
 dimensions are nominal values in inches
 (mm referenced).