

Type 228A Differential Capacitance Manometer Pin-outs

Pin/Color	Description
1/Grey	Relay A, Normally Open
2/Red	Pressure Output Signal
3/Tan	Relay A Common
4/Yellow	Relay A, Normally Closed
5/Orange	Power Ground
6/White	- Power Supply Input
7/Green	+ Power Supply Input
8/Violet	Relay B Normally Open
9/Blue	Relay B Common
10/Brown	Relay B Normally Closed
11/n/a	Trip Point Adjust Common
12/Black	Pressure Return
13/n/a	Trip Point A Adjust
14/n/a	Trip Point B Adjust
15/Bare	Chassis Ground

This information is subject to change without notice.