DA02B

Absolute Baratron® Capacitance Manomete with EtherCAT® Communications (Full Scale Pressures from 0.1 to 1000 Torr)*



Please Note

* Not recommended for new designs. For new applications see DA05A for Full Scale pressures <1 Torr/mbar and DA07A for Full Scale pressures 1 Torr/mbar and greater.

For well over half a century, the MKS Baratron® capacitance manometers have led the industry in performance, accuracy, reliability, and worldwide installed base. The DA02B Baratron capacitance manometer continues that progression of high performance into networked systems, using industry-standard EtherCAT digital communications to connect to complex process tools.

Based on the proven E28 and 600 Series absolute analog manometer products, the DA02B meets the current ETG.5003 Semiconductor Device Profile and is designed for use in advanced manufacturing systems. It uses the

same Inconel®-based capacitance sensor as analog communication Baratron manometer products, and thus offers the same long lifetime, low maintenance, and high corrosion resistance. Two (2) independently configurable solid state trip relays for pressure are available as an option to permit the control of external components. It is available in unheated or heated to 45°C, 80°C, or 100°C versions, Full Scale measurement ranges from 0.1 to 1000 Torr (13.3 Pa to 133.3 kPa), and a wide variety of different connection fittings for use in a wide range of applications.

Product Features

- Includes both analog output and EtherCAT communications
- Full Scale measurement ranges from 0.1 to 1000
 Torr (13.3 Pa to 133.3 kPa)
- Available in unheated or heated to 45°C, 80°C, or 100°C versions
- Available with EtherCAT standard +24VDC or traditional ±15 VDC input power configuration
- Deposition/fluorine friendly sensor option available
- Optional deposition traps are available to minimize process buildup in the manometer
- Push button zero



Key Benefits

- Industry-leading accuracy and repeatability
- Inconel-based sensor offers superior corrosion resistance to common process gases
- Excellent long-term stability

^{*} Not recommended for new designs. For new applications see DA05A for Full Scale pressures < 1 Torr/mbar and DA07A for Full Scale pressures 1 Torr/mbar and greater.

Specifications

Please Note * Not recommended for new designs. For new applications see DA05A for Full Scale pressures <1 Torr/mbar and DA07A for Full Scale pressures 1 Torr/mbar and greater.

Full Scale Ranges ¹	0.1, 0.25, 1, 2, 10, 20, 100, 200, 500, and 1000 Torr (and metric equivalents)		
Resolution ²	0.001% Full Scale		
Operating Temperatures Unheate 45° 80°C and 100°	 0 to 50°C 15° to 40°C 15° to 50°C 		
Accuracy ^{3,4} Unheate	• 0.50% of Reading for ranges < 1 Torr 0.25% of Reading for ranges ≥ 1 Torr		
45°	 0.15% Reading for ranges < 1 Torr 0.10% of Reading for ranges ≥ 1 Torr 		
80°C and 100°	• 0.50% of Reading for ranges < 1 Torr 0.25% of Reading for ranges ≥ 1 Torr		
Temperature Coefficients - Zero Unheate	 0.020% Full Scale/°C for < 1 Torr 0.015% Full Scale/°C for 1 Torr 0.010% Full Scale/°C for 2 Torr 0.005% Full Scale/°C for 10 to 1000 Torr 		
45°0	 0.005% Full Scale/°C for ranges < 1 Torr 0.002%% Full Scale/°C for ranges ≥ 1 Torr 		
80°C and 100°	0.010% Full Scale/°C for ranges < 1 Torr 0.002% Full Scale/°C for ranges ≥ 1 Torr		
Temperature Coefficients - Span Unheate Heate	J. 1		
Materials Exposed to Gases	Inconel and Incoloy nickel alloys (Fittings are made from 300 series stainless steel)		
Internal Sensor Volume	6.3 cm³ for ½" OD tube fitting. Volumes with other fitting available on request		
Warmup Time	2 hours for ranges ≥ 1 Torr; 4 hours for ranges < 1 Torr		
Overpressure Limit	45 psia (310 kPa)		
Input Power Unheate 45° 80°C and 100°	 +24 VDC ±10% @ 300 mA or ±15 VDC @ 300 mA +24 VDC ±10% @ 600 mA or ±15 VDC @ 600 mA +24 VDC ±10% @ 800 mA or ±15 VDC @ 800 mA 		
Output Signal Analo Digita	 0 – 10 VDC into > 10 kΩ load EtherCAT 		
Response Time EtherCAT Update Rat	a 3.3 ms		
Trip Relay Option	Two (2) internally mounted process pressure trip relays, solid state, independently adjustabe through EtherCAT by customer at atmospheric pressure from 0.5% to 100% of Full Scale range. Relay capacity of 0.20 amps@ 30 VDC. Complies with UL1577 requirements. Trip point option also includes two similar relays for "at temperature" and heater error status.		
Electrical Connectors Analo EtherCA			
External Indicators	Multicolor status LED and two (2) red/green LEDs for EtherCAT communications status		
Connection Fittings Standar Options			
Compliance ⁵	CE, ETG.5003.2080 Vacuum Pressure Gauge		

¹ Not recommended for new designs. For new applications see DA05A for Full Scale pressures <1 Torr/mbar and DA07A for Full Scale pressures 1 Torr/mbar and greater.

² Theoretical resolution under ideal laboratory conditions. Actual resolution in service is usually determined by system design factors not under MKS's control.

 $^{^{\}scriptscriptstyle 3}$ Includes non-linearity, hysteresis, and non-repeatability.


⁴ Accuracy specification and NIST-traceable calibration points included on calibration sheet are from Full Scale to 10% of Full Scale.

 $^{^{\}rm 5}$ When connected to a properly shielded cable, grounded at both ends.



Dimensional Drawings

Please Note * Not recommended for new designs. For new applications see DA05A for Full Scale pressures <1 Torr/mbar and DA07A for Full Scale pressures 1 Torr/mbar and greater.





Please Note

* Not recommended for new designs. For new applications see DA05A for Full Scale pressures <1 Torr/mbar and DA07A for Full Scale pressures 1 Torr/mbar and greater.

Ordering Code Example: DA02B11TCES24C00AA	Code	Configuration
Model		
DA02B Baratron Digital Capacitance Manometer	DA02B	DA02B
Pressure Range*		
0.1 0.25 1 2 10 20 100 200 500 1000	.1 RE 01 02 11 21 12 22 52 13	11
Units of Measurement		
Torr absolute mbar absolute kPa absolute	T M K	Т
Fittings		
1/2" OD tube 8 female VCR 8 male VCR 8 female VCR, short inlet tube (use with sensor type T or M) KF16 KF25 1.33" OD CF (rotatable)	BA CE CF CR GA GC HA	CE
Sensor Type		
Standard sensor, standard inlet tube length Standard sensor, reduced inlet tube length (use with fitting code CR) Deposition/etch/fluorine friendly sensor (range to 20 Torr) Short tube deposition/etch/fluorine friendly sensor (range to 2 Torr, use with fitting code CR)	S T L M	S
Input/Output Voltages		
+24 VDC or ±15 VDC input, 0-10 VDC analog output	2	2
Sensor Temperature		
Unheated 45°C 80°C 100°C	0 4 8 1	4
Electrical Connector		
(2) RJ45 EtherCAT jacks with 15-pin D-subminiature connector	С	С
Calibration Orientation (select V or H for range ≤ 1 Torr)		
Standard (ranges > 1 Torr) Vertical (standard for ranges ≤ 1 Torr) Horizontal (available for ranges ≤ 1 Torr only)	0 V H	0
Accuracy		
Standard accuracy	0	0
Trip Points**		
None Trip A above 50%, Trip B above 50% of Full Scale Range Trip A above 50%, Trip B below 50% of Full Scale Range Trip A below 50%, Trip B below 50% of Full Scale Range Trip A below 50%, Trip B above 50% of Full Scale Range	None AA AB BB BA	АА



Notes:

Not recommended for new designs. For new applications see DA05A for Full Scale pressures <1 Torr/mbar and DA07A for Full Scale pressures 1 Torr/mbar and greater.

** Units with trip points have default setpoints and actuation direction based on the part number code but are user adjustable through EtherCAT.

Custom part numbers can be requested for copy exact applications. Standard part numbers ship with latest firmware at the date of manufacture. A custom part number should be requested for locked firmware/EtherCAT® ESI file.

Some Baratron® capacitance manometer products may not be exported to many end user countries without both US and local government export licenses under ECCN 2B230. Baratron® is a registered trademark of MKS Instruments, Inc. or a subsidiary of MKS Instruments, Inc. All other trademarks cited herein are the property of their respective owners.